


DESK 3 SHELVES 2 DRAWERS

ASSEMBLY INSTRUCTIONS




TIPS BEFORE YOU START

1. Please check that all parts are present before you start the assembly of your furniture.
2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
3. For larger items, please ensure that you have sufficient space and people to assemble your product safely.
4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
5. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
6. During assembly please take care not to over-tighten any fittings, as this may damage the product. Do not use power tools.
7. Always place the product on a flat, steady and stable surface.
8. Do not stand on the product. Do not use the product as a stepladder.
9. This product is intended for indoor, household use only as it is a non-industrial product.
10. Please use caution and care when lifting the product to avoid personal injury and/or product damage.


CARE AND MAINTENANCE OF YOUR FURNITURE

- ✓ Please periodically check all fittings and re-tighten as necessary.
- ✓ To clean your item, please use a damp cloth and wipe clean.
- ✓ To clean glass, please use glass cleaner.
- ✓ Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- ✓ Please do not place hot items (eg. hot drinks) directly on to the surface.
- ✓ Please do not drag and pull your furniture.



ASSEMBLY REQUIREMENTS


- ✓ Equipment: phillips head screwdriver, flat head screwdriver and hammer
- ✓ 2 x adults required
- ✓ 2m x 2m assembly space required
- ✓ 2 hour assembly time approx.



USING CAM LOCK AND QUICKFIT


QUICKFIT

Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.





CAM LOCK

When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.



Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.


Turn cam lock clockwise to tighten.




HARDWARE LIST



10 x A
Cam Lock




10 x B
Quickfit Screw



10 x C
Cam Lock Cover




16 x D
Wooden Dowel




6 x E
Screw



1 x F
Allen Key



54 x G
Screw




16 x H
Screw



4 x I
Outer Drawer Runner




4 x J
Inner Drawer Runner




6 x K
Leg Support


PARTS LIST




1
1 PC




2
1 PC




3
1 PC




4
1 PC




5
1 PC



6
1 PC




7
1 PC



8
2 PCS




9
2 PCS



10
4 PCS



11
2 PCS



12
2 PCS







13
4 PCS

ASSEMBLY INSTRUCTIONS

STEP 1





Insert cam locks (A), quickfit screws (B) and wooden dowels (D) to parts 1 and 6, as shown.



ASSEMBLY INSTRUCTIONS

STEP 2




Insert cam locks (A), quickfit screws (B) and wooden dowels (D) to parts 3, 4 and 5, as shown.



ASSEMBLY INSTRUCTIONS

STEP 3




Fix outer drawer runners (I) to part 3 using screws (G), as shown.



ASSEMBLY INSTRUCTIONS

STEP 4

Fix outer drawer runners (I) to part 5 using screws (G), as shown.





ASSEMBLY INSTRUCTIONS

STEP 5

Attach part 5 to part 6, as shown.

Turn cam locks clockwise to tighten.

Attach cam lock cover (C), as shown.





ASSEMBLY INSTRUCTIONS

STEP 6

Attach parts 3 and 4 to parts 5 and 6, as shown.

Turn cam locks clockwise to tighten.

Attach cam lock cover (C), as shown.





ASSEMBLY INSTRUCTIONS

STEP 7

Attach parts 3 and 4 to part 1.

Turn cam locks clockwise to tighten.


Attach cam lock cover (C), as shown.



ASSEMBLY INSTRUCTIONS

STEP 8




Insert part 7 into grooves between parts 3, 4 and 6, as shown.



ASSEMBLY INSTRUCTIONS

STEP 9


Fix part 2 to parts 3, 4 and 5 using screws (E) tighten with allen key (F), as shown.



ASSEMBLY INSTRUCTIONS

STEP 10


Fix leg supports (K) to parts 1 and 2 using screws (G), as shown.



G x 30



K x 6




ASSEMBLY INSTRUCTIONS

STEP 11

Screw part 12 to part 1.



Screw part 13 to part 2, as shown.



ASSEMBLY INSTRUCTIONS

STEP 12


Fix parts 10 to parts 8 and 9 using screws (H), as shown.



ASSEMBLY INSTRUCTIONS

STEP 13



Insert parts 11 in to grooves between parts 8, 9 and 10, as shown.



ASSEMBLY INSTRUCTIONS

STEP 14




Fix parts 10 to assembled drawers using screws (H), as shown.



ASSEMBLY INSTRUCTIONS

STEP 15


Fix inner drawer runners (J) to parts 10 using screws (G), as shown.



ASSEMBLY INSTRUCTIONS

STEP 16

Insert drawers in to desk, as shown.




ASSEMBLY INSTRUCTIONS

STEP 17

Maximum recommended weight is 20kg on top, 10kg inside drawers and 10kg on shelves.

Your desk is ready for use.



WALL FIXING GUIDE

NOTE: Supplied wall plugs are only suitable for use in masonry walls.

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.



IMPORTANT: When drilling into walls, always check for hidden wires or pipes, etc.




Tips & Tricks

Make sure that the hardware used is suitable for supporting your unit. Please consult a qualified tradesperson if unsure.

- Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- If you are unsure, please select a larger screw and wall plug.
- Ensure that you use the recommended drill bit to match the wall plug and hole size.
- Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.


Types of Walls

Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




1. General Purpose Wall Plug

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




2. Plasterboard Wall Plug

For use when attaching light loads onto plasterboard partitions.




3. Cavity Fixing Wall Plug

For use with plasterboard partitions or hollow wooden doors.




4. Cavity Fixing Heavy Duty Wall Plug

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



5. Hammer Fixing Wall Plug

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.



6. Shield Anchor Wall Plug Heavy Loads

For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc.