ADJUSTABLE SQUAT RACK

USER MANUAL




PART LIST








The weighe plate storage pole(K) should be fastened by screw M10X70. The installation of base fame(A) is same for both sides.



The red metal plates(M) should be attached on the outer side of both base frame. Use 2PCS M10X70 bolts to fasten the red metal plates as shown in the figure.

STEP 2




Make sure the outer mounting point in the middle of main frame(D) is facing to right side as shown in the figurte.

Install the main frame(D) on the base, use 2PCS of M10X70 bolts to fasten the main frame(D).

Attach the bar(J) on the outer mounting point of main frame(D). Use one M8X55 bolt to fasten the bar first, the bolt should be inserted into the left mounting hole.

The installation of main frame(D) is same for both sides.



Make sure the outer mounting point in the middle of front main frame(G) is facing to left side as shown in the figurte. Install the front main frame on the base, connect the horizonal bar(J) at the same time.

Insert the front inner tube(H) into the front main frame(G) , use knob screw(N) to hold the position.

Install the barbell holder(I) on the top of the inner tube(H).

Fasten the parts by different bolts as shown in the figure. The installation of front main frame (G) is same for both sides.

