
SHOE CABINET
2 DOORS

ASSEMBLY INSTRUCTIONS



TIPS BEFORE YOU START


1. Please check that all parts are present before you start the assembly of your furniture.
2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
3. For larger items, please ensure that you have sufficient space and people to assemble your product safely.
4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
5. For the protection of your furniture, we recommend that the product is placed on a protective surface during assembly to prevent any damage.
6. During assembly please take care not to over-tighten any fittings, as this may damage the product. Do not use power tools.
7. Always place the product on a flat, steady and stable surface.
8. Do not stand on the product. Do not use the product as a stepladder.
9. This product is intended for indoor, household use only as it is a non-industrial product.
10. Please use caution and care when lifting the product to avoid personal injury and/or product damage.

CARE AND MAINTENANCE OF YOUR FURNITURE

- ☑ Please periodically check all fittings and re-tighten as necessary.
- ☑ To clean your item, please use a damp cloth and wipe clean.
- ☑ To clean glass, please use a glass cleaner.
- ☑ Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to delaminate.
- ☑ Please do not place hot items (e.g. hot drinks) directly onto the surface.
- ☑ Please do not drag or pull the furniture.

ASSEMBLY REQUIREMENTS

- ☑ Equipment: Phillips screwdriver, flat-head screwdriver
- ☑ 2 adults required
- ☑ 2 m x 2 m assembly space required
- ☑ Approx. 1.5 hours assembly time



ANTI-TOPPLING WARNING

⚠CHILDREN HAVE DIED FROM FURNITURE TIPOVER.

- **ALWAYS** secure this furniture with an anchor device
- **NEVER** allow children to stand, climb or hang on drawers, doors or shelves
- **NEVER** open more than one drawer at a time
- **NEVER** put a TV on this furniture
- Place heavy items down low


For more information, visit https://www.productsafety.gov.au



USING CAM LOCK AND QUICKFIT


QUICKFIT

Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.




CAM LOCK


When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.



Quickfit head should be in the centre of the cam lock when the two panels are joined. Cam lock should be inserted before quickfit.



Turn cam lock clockwise to tighten.



HARDWARE LIST




16 x A
Quickfit Screw




16 x B
Camlock



12 x C
Wooden Dowel



6 x D
Screw



12 x E
Wedge



12 x F
Screw




16 x G
Shelf Support




18 x H
Screw




4 x I
Washer




2 x J
Wall Strap




2 x K
Wall Plug



4 x L
Adjustable Feet



4 x M
Screw




2 x N
Handle


PARTS LIST



1
1 PC



2
4 PCS



3
1 PC




4
1 PC




5
1 PC




6
1 PC



7
1 PC



8
1 PC



9
3 PCS



10
2 PCS





11
4 PCS

ASSEMBLY INSTRUCTIONS

STEP 1

Insert quickfit screws **A** parts **6** and **7**.






STEP 2


Insert cam locks **B** and wooden dowels **C** to parts **3** and **10**.

Fix parts **3** and **10** to part **6**.

Turn cam locks clockwise to tighten.








STEP 3

Insert part **9** into the grooves of parts **6** and **10**.




STEP 4


Insert cam locks **B** and wooden dowels **C** to parts **3** and **10**.

Fix parts **3** and **10** to part **7**.

Turn cam locks clockwise to tighten.









STEP 5


Insert part **9** into the grooves of parts **6 , 7** and **10**.



STEP 6

Insert quickfit screws **A** part **1**.






STEP 7


Insert cam locks **B** and wooden dowels **C** to parts **6** and **7**.

Fix parts **6** and **7** to part **1**.

Turn cam locks clockwise to tighten.


.





STEP 8

Insert part **9** into the grooves of parts **6**, **7** and **10**.





ASSEMBLY INSTRUCTIONS


STEP 9

Insert wooden dowels **C** to parts **6** and **7**.

Fix parts **6** and **7** to part **4** using screws **D**.









STEP 10

Fix parts **11** to part **4** using screws **H**.

Screw adjustable feet **L** to part **11**.









STEP 11


Fix handle **N** parts **5** and **8** using screws **M**.






STEP 12

Slide part **5** into the grooves of parts **1** and **4**.




STEP 13

Slowly slide part **5** into the grooves of parts **1** and **4**.




STEP 14

Slide part **8** into the grooves of parts **1** and **4**.



STEP 15


Slowly slide part **5** into the grooves of parts **1** and **4**.




STEP 16

Secure the assembled unit using wedges **E** and screws **F**.

Fix wall strap **J** to part **1** using washers **I** and screws **H**.



STEP 17




For extra stability,you must fix your Shoe Cabinet to the wall using the additional hardware K, I and D.

Firstly, screw wall plug K into required position in your wall.


Screw D is fixed through wall strap J, washers I and into the wall plug K in your wall.

Should you choose not to affix the product to the wall, serious injury may be caused if the product tips over.






STEP 18




Insert shelf support **G** to parts **6** and **7**.

Place parts **2** onto shelf support **G**.



STEP 19



Maximum recommended weight is 30kg on top and 6kg kg on each shelf.

Your Shoe Cabinet 2 Doors is ready for use.

WALL FIXING GUIDE

NOTE: Supplied wall plugs are only suitable for use in masonry walls.

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.

IMPORTANT:
When drilling into walls, always check for hidden wires or pipes, etc.


Tips & Tricks

Make sure that the hardware used is suitable for supporting your unit. Please consult a qualified tradesperson if unsure.

- ☑ Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ☑ If you are unsure, please select a larger screw and wall plug.
- ☑ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ☑ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.


Types of Walls

Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




1. General Purpose Wall Plug

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




2. Plasterboard Wall Plug

For use when attaching light loads onto plasterboard partitions.




3. Cavity Fixing Wall Plug

For use with plasterboard partitions or hollow wooden doors.




4. Cavity Fixing Heavy Duty Wall Plug

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



5. Hammer Fixing Wall Plug

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.



6. Shield Anchor Wall Plug Heavy Loads

For use with concrete or brick walls, or for use with heavier loads such as TV & WiFi speakers, satellite dishes, etc.