



**EXPLODED VIEW**

**Item Description**

1-13. Shower Diverter Complete

14. Shower Arm

15. Washer

16. Shower Head

17. Shower Hose

18. Hand Shower

**Installation Steps:**

**1. Remove out wall end from diverter.**

**2. Connect wall end to pipe tightly.**

**3. Put shower arm into diverter, tighten with screw.**

**4. Connect diverter with shower arm to wall end, tighten with screw.**

**5. Connect the overhead shower head to the shower arm connector tightly.**

**6. Connect the water hose to the connector at the bottom of diverter tightly.**

**7. Connect the handheld shower to water hose tightly.**

**(Typically the plumber's tape is wrapped around a pipe's thread before it is screwed into place.)**