

ASSEMBLY
INSTRUCTION

STUDY DESK

Read this instruction carefully. See hardware and furniture list for guidance. Be sure all part is complete before you assemble. Place all wooden part on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

- CAUTIONS:
- 1. Do not FULLY-TIGHTEN the nut or nut bolt until all nut or bolts is ready assembled.
 - 2. Do not OVER-TIGHTEN the nut or nut bolt to avoid causing damages to the thread.
 - 3. Keep all hardware part out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

A		B				C		D
	B1		B2		B3		B4	
WOOD DOWEL M6 x 30mm	MINIFIX	EURO BOLT - H	MINIFIX FOR DRAWER	EURO BOLT - KD	JCBC M6 x 45mm	CAP	CB SCREW M6 x 10mm	
X 44 PCS	X 8 PCS	X 8 PCS	X 6 PCS	X 6 PCS	X 23 PCS	X 9 PCS	X 9 PCS	
E		F	G1	G2	G3	H	I	J
14" DRAWER SLIDE	CB SCREW M3.5 x 10mm	JCBC M6 x 10mm	SPRING WASHER	FLAT WASHER	WOOD DOWEL M6 x 30mm	HANDLE 200mm	ALLEN KEY M4	
X 2 SETS	X 28 PCS	X 4 PCS	X 4 PCS	X 4 PCS	X 16 PCS	X 2 PCS	X 1 PC	

Step 1

Step 2

Step 3

Step 4

Step 5

Step 6

Step 8

Step 9

Step 11

Step 13

Step 10

Step 12

COMPLETED ASSEMBLY