

"Must not drag or push after assembly. Please always lift the item for moving".

PART LIST

1. Headboard  X1	2. Footboard  X1	3. Support Leg  X2	4. Sideboard  X2	5. Bottom support Rail  X1
6. Slats  X24	7. Double-hole Plastic Cap  X12	8. Single-hole Plastic Cap  X24	9. Legs  X4	10. Slat side bar  X2
11. Slat side bar  X2	12. Slat center bar  X1	13. Bracket  X2	14. Bottom panel  X2	15. Lifting frame 16. Piston  X2
17. Strap handle  X1	18. Mattress stopper  X1	19. Stabilizer bar  X1	20. Stop Cube  X1	21. Wings  X2

HARDWARE LIST

(A) Bolt M8*30mm  X32	(B) Allen key  X1	(C) Nut M8  X6	(D) Spring Washer  X8	(E) Flat Washer  X65
(F) Spanner  X1	(G) Bolt 8*50mm  X5	(H) Bolt 8*40mm  X12	(I) Bolt 6*20  X4	(J) Bolt 8*20mm  X12
(K) Mute sticker  X5				

Step 1	Step 2
Step 3	Step 4
Step 5	Step 6
Step 7 Pay attention to keep the order of parts 10 consistent, and keep the three holes in the same horizontal line	Step 8
Step 9	Step 10
Step 11	