PAGE: 1/10 MODEL: MFC 7915 OAK


Before you begin, please follow assembly instructions carefully, then follow them step by step.


Read instruction carefully . See Furniture Parts list and Hardware List for guidance . Be sure you have all parts before you start assembling . Place and assemble furniture on a clean flat soft surface, such as carpet or rug to pervent being scratched.

PART LIST		QTY
1	TOP PANEL	1 PC
2	BOTTOM PANEL	1 PC
3	SIDE PANEL (L)	1 PC
4	SIDE PANEL (R)	1 PC
5	CENTER PANEL (L)	1 PC
6	CENTER PANEL (R)	1 PC
7	MIDDLE PANEL	2 PCS
8	DOOR PANEL	2 PCS
9	SHELF PANEL	2 PCS
10	BACK PANEL	1 PC
11	DRAWER FRONT	3 PCS
12	DRAWER SIDE	6 PCS
13	DRAWER BACK	3 PCS
14	DRAWER BOTTOM	3 PCS
15	LEG	4 PCS

1	DRAWER FRONT	3 PCS						
2 DRAWER SIDE			6 PCS					
3 DRAWER BACK			3 PCS					
4	DRAWER BOTTOM			3 PCS				
5 LEG			4 PCS					
SELF-PREPARED TOOLS: Tools below are NOT included in package.								
SCREWDRIVER HAMMER								
		POWER DRILL						

calpet of rug to pervent being scrattified .						
HARDWARE						
Α	MINI FIX A1 👺 A2 👊	⇒ 3 ⇔	12 PCS			
В	M8 X 30MM WOOD DOWEL		20 PCS			
С	M6 X 50MM CSK CAP WOOD SCREW	dammaman>	8 PCS			
D	M4 X 38MM C.B SCREW	() numum>	24 PCS			
Е	M3.5 X 16MM C.B SCREW	() mmm>	52 PCS			
F	METAL SHELF SUPPORT	D	8 PCS			
G	ALLEN KEY M4		1 PC			
Н	5/8 NAIL	0	70 PCS			
I	14" DRAWER SLIDE	11 (L/R) 12 (L/R)	3 SETS			
J	7/8 HINGES		4 SETS			
K	HANDLE 0161-128		5 PCS			
L	HANDLE SCREW M4 x 19MM	()	10 PCS			
М	JCBC SCREW M6 x 70 0000		8 PCS			
Ν	SPRING WASHER M6		8 PCS			
0	FLAT WASHER M6	0	8 PCS			
Р	TIPPING PACK 11 P1 P3 P3 P5		2 SETS			





Reminder:

Please ensure that all surfaces and edges with colours/laminations are facing forward/outward.

PAGE: 2/10

MODEL: MFC 7915 OAK


STEP 1

Insert hardware A2 onto panel (1). (Repeat 8 times.)



STEP 2


- Insert hardware A1 onto panel (3). (Repeat 2 times.)
- Insert hardware B onto panel (3). (Repeat 4 times.)



* Ensure the arrows on hardware A1 point towards mounting positions.

STEP 3


- Insert hardware A1 onto panel (4). (Repeat 2 times.)
- Insert hardware B onto panel (4). (Repeat 4 times.)




* Ensure the arrows on hardware A1 point towards mounting positions.

STEP 4

- Insert hardware A1 onto panel (5). (Repeat 2 times.)
- Insert hardware B onto panel (5). (Repeat 4 times.)



* Ensure the arrows on hardware A1 point towards mounting positions.



PAGE: 4/10

MODEL: MFC 7915 OAK

STEP 9

- Insert hardware A1 onto panel (6). (Repeat 2 times.)


- Insert hardware **B** onto panel (6). (Repeat 4 times.) **x2** RIGHT FACE

* Ensure the arrows on hardware A1 point towards mounting positions.

STEP 10

- Insert hardware A1 onto panel (7). (Repeat 4 times.)

- Insert hardware **B** onto panel (7). (Repeat 4 times.)




* Ensure the arrows on hardware **A1** point towards mounting positions.

STEP 11

- Attach panel (5) to panel (7). - Insert all hardware A2 into A1.

- Rotate all A1 until tight.



PRESS

* In this step hardware A1, A2 and B are pre-inserted.



SCREWDRIVER

REQUIRED


HARDWARE G

OR

- Attach panel (6) to panel (7).

- Rotate all A1 until tight.

- Apply **A3** onto all **A1**. (Repeat 2 times.)



* In this step hardware A1, A2 and B are pre-inserted.



PAGE: 5/10


MODEL: MFC 7915 OAK



- Attach panel (1) to panel (5) and (6). - Insert all hardware A2 into A1.

- Rotate all A1 until tight.

- Apply A3 onto all A1. (Repeat 4 times.)



* In this step hardware A1, A2 and B are pre-inserted.


* In this step hardware A1, A2 and B are pre-inserted.


STEP 14

- Attach panel (1) to panel (3).

- Insert all hardware A2 into A1.

- Rotate all A1 until tight.






* In this step hardware A1, A2 and B are pre-inserted.

STEP 15

- Attach panel (1) to panel (4).


- Rotate all A1 until tight.



STEP 16

SCREWDRIVER REQUIRED

Connect panel (2) to panel (3), (4), (5) and (6) by using hardware C and G.




PAGE: 6/10


MODEL: MFC 7915 OAK

STEP 17

Assemble part 16 into panel (2) by using hardware G, M, N and O.




STEP 18



STEP 19

Fix hardware F into panel (3), (4), (5) and (6). (Repeat 8 times.)



STEP 20

Assemble the panel (9) into between panel (3), (4), (5) and (6). (Repeat 2 times.)

