

Installation Instruction:

1. Place item in desired position.
2. Mark centres for fixing bracket.
3. Mark and drill holes for fixing bracket.
4. If unable to screw into studs, use toggle anchors for cavity walls.
5. Use nylon plug for brick or masonry to attach bracket to the wall.
6. Screw the mounting bracket to the wall.
7. Place main body and carefully tighten grub screw underneath.