



1

Secure the Mounting Arm onto the Towel Ladder by fastening the M6 Screw, and Washer using the 5mm Allen Key.

Repeat this with the remaining Mounting Arms

2

Insert Mounting Plates into the top Mounting Arms.

Position Towel Ladder in preferred location.

NOTE

It is recommended that the top Mounting Plates are fitted and adjusted first before fitting the bottom Mounting Plates.

3

Ensure the Towel Ladder is level.

Mark the left and right hole on the Mounting Plate.

MOUNTING KIT

- 4 x Self Tapping Screw
- 4 x Wall Plug
- 4 x Screw with Spring Toggle
- 1 x 3mm Allen Key
- 1 x 5mm Allen Key

4

For fixing to brick walls with hard plaster or ceramic tiled surface:

Using a 6mm masonry drill bit, drill 2 holes 30mm deep. Press plugs into holes. Guide Self Tapping Screws through the Mounting Plate, into the plastic plugs and tighten with screwdriver.

For fitting to stud walls clad with wallboard, with or without ceramic tiles:

Using a 10mm drill bit, drill through to wall cavity. Remove Screws from Spring Toggles. Guide Screws through the Mounting Plate, screw on the Spring Toggles and push them into the holes. Tighten with screwdriver.

5

Push Mounting Plates into lower Mounting Arms.

Fit Towel Ladder onto top Mounting Plates.

Mark hole positions for the lower Mounting Plates.

REPEAT STEP 4

NOTE

Lower holes should be marked vertically.

6

Place Dress Plates over Mounting Plates.

Push Towel Ladder onto Mounting Plates.

Insert Grub Screws into holes in each Mounting Arm.

Tighten with 3mm Allen Key provided.