

Mark the desired position of the accessory with a pencil.

Drill holes and push in appropriate Wall Plugs.

Fasten the pillar to the wall with Screws.

Fasten Robehook to the pillar.

