

- 1
- Apply Teflon Tape to Threaded Elbow.
- Fit Dress Plate over the Threaded Elbow.
- Firmly screw on the Shower Arm.



