



- Apply Teflon Tape to Threaded Elbow.
- Firmly screw the Shower Arm onto the Threaded Elbow.



