











## QUEEN BED

**CAUTIONS:**

1. Do not **FULLY-TIGHTEN** the nut or nut bolt until all nut or bolts is ready assembled.
2. Do not **OVER-TIGHTEN** the nut or nut bolt to avoid causing damages to the thread.
3. Keep all hardware part out of reach of children.

**NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.**

A	B	C	D	E	F	G			H	I
										
WOOD DOWEL M8 X 30MM	HEX FLANGE NUT M6	SPANNER 10MM	PLASTIC COVER 35MM	HEX FLANGE BOLT M6 X 30MM	CB SCREW M4 X 20MM	JCSC M4 X 60MM	SPRING WASHER	FLAT WASHER	ALLEN KEY M4	CB SCREW M4 X 32MM
X 20 PCS	X 14 PCS	X 1 PC	X 2 PCS	X 3 PCS	X 3 PCS	X 4 PCS	X 18 PCS	X 4 PCS	X 1 PC	X 30 PCS

