


Assembly Instructions

LATROBE 160 CM ENTERTAINMENT UNIT



MAXIMUM WEIGHT CAPACITY OF THIS UNIT IS 30 KG.

Please read the Assembly Instructions carefully
before assembling.

Imported by PRODESIGN FURNITURE PTY LTD.

WARNING

FAILURE TO FOLLOW THESE BASIC STEPS CAN LEAD TO DAMAGE THAT IS NOT COVERED BY YOUR WARRANTY

1. Read Instructions carefully. Check no parts are missing.
2. Lay out all of the components on a soft surface as if you were preparing to do a jigsaw puzzle.
3. Carefully identify each component , especially those that are similar. The most common mistake is getting things back to front.
4. Separate and identify each component from the hardware pack and rest each one in its proper location before fastening.
5. **DO NOT** fully tighten screws (leave slightly loose). When the item is fully assembled tighten the screws - but do not over tighten.

Warning: In order to prevent overturning this product must be used with the wall attachment device provided.

Daily Care :


Water and other liquids can cause discoloration and damage to the surface. In case any liquids are spilled on the surface, remove immediately with a clean cloth. Avoid rubbing the spilled liquid into the veneer, but wipe gently, using a clean, firmly wrung damp cloth. If stains or marks persist, seek professional help and advice.

Woods expands and contracts according to the surrounding humidity and temperature. In case of temperature and humidity fluctuations, the wood might warp and/or crack. To avoid this, do not place the furniture near a radiator or in hot surroundings.











Take care when moving the furniture across the floor. Do not drag the furniture, as this can cause damage to both the furniture and the floor.

What you need

To assemble the product






NO.	PART LIST	QTY	NO.	PART LIST	QTY
(1)	Top Panel	1	(7)	Side Shelf	2
(2)	Bottom Panel	1	(8)	Middle Shelf	1
(3)	Left Panel	1	(9)	Rear Panel	1
(4)	Right Panel	1	(10)	Back Panel	1
(5)	Left Divider	1	(11)	Metal Support	1
(6)	Right Divider	1	(12)	Door	3

 <p>14 x Cam Lock Ø15x12mm (A)</p>	 <p>14 x Cam Bolt Ø7.5x32mm (B)</p>	 <p>14 x Cam Cap Ø17mm (C)</p>	 <p>21 x Plastic Dowel Ø8x32mm (D)</p>
 <p>6 x Screw Ø6x8mm (E)</p>	 <p>3 x Push To Open (F)</p>	 <p>8 x Screw Ø10x33.5mm (G)</p>	 <p>5 x Screw Ø6x45mm (H)</p>
 <p>5 x washer Ø6mm (I)</p>	 <p>2 x Screw Ø4x10mm (J)</p>	 <p>3 x Screw Ø3x12mm (K)</p>	 <p>1 x Wall Bracket (L)</p>
 <p>12 x Shelf pin (M)</p>	 <p>4 x Full Curve Door Hinge (N)</p>	 <p>2 x Half Curve Door Hinge (O)</p>	 <p>8 x Screw Ø4x19mm (P)</p>
 <p>8 x Backply Stopper (Q)</p>			


As all installation environments are different you may not have all the necessary installations hardware provided in the hardware pack supplied with this unit. If you require further fixings please visit your local hardware store and purchase other required fixings. The fixings provided in this pack are for a basic install only.

Please make sure you have all these parts before you start.



Step 1

You will need		
		
8 x Cam Bolt (B)	6 x Screw (E)	3 x Push To Open (F)


Screw 8 x Cam Bolts (B) into Top Panel (1).
Attach 3 x Push To Open (F) using 6 x Screws (E).



Step 2

You will need	
	
6 x Cam Bolt (B)	4 x Plastic Dowel (D)

Screw 6 x Cam Bolts (B) into Left Panel (3) and Right Panel (4).
Insert 4 x Plastic Dowel (D) into Left Panel (3) and Right Panel (4).
If necessary, gently tap the Plastic dowels with a mallet.





Step 3

You will need



8 x Plastic Dowel (D)

Insert 8 x Plastic Dowel (D) into Left Divider (5) and Right Divider (6).
If necessary, gently tap the Plastic dowels with a mallet.





Step 4

You will need





9 x Plastic Dowel (D)

Insert 9 x Plastic Dowel (D) into Bottom Panel (2) and Rear Panel (9).
If necessary, gently tap the Plastic dowels with a mallet.




Step 5

You will need


 5 x Screw (H)	 5 x washer (I)
---	--

Attach Metal Support (11) to Bottom Panel (2) using 5 x screws (H) and 5 x Washer (I).
Tighten the Screws 50% before fix it.




Step 6

You will need


 4 x Screw (G)

Attach Rear Panel (9) to Bottom Panel (2) using 4 x Screws (G).




Step 7

You will need




4 x Screw
(G)

Attach Left Divider (5) and Right Divider (6) to Bottom Panel (2) using 4 x screws (G).




Step 8


You will need



6 x Cam Lock
(A)




6 x Cam Cap
(C)




2 x Screw
(J)

Attach Left Panel (3) and Right Panel (4) to case assembly using 6 x cam lock (A) as shown, Use a screwdriver to turn the Cam lock clockwise to lock. Paste 6 x Cam Cap (C) as shown. Tighten metal support (11) with Left Panel (3) and Right Panel (4) using 2 x screws (J) as shown. Tighten screws (H) 100% and fix it.





Step 9


Insert Back Panel (10) into case assembly as shown.







Step 10

You will need	
	
8 x Cam Lock (A)	8 x Cam Cap (C)


Attach Top Panel (1) to case assembly using 8 x Cam lock (A) as shown, Use a screwdriver to turn the Cam lock clockwise to lock. Paste 8 x Cam Cap (C) as shown.




Step 11

You will need			
			
3 x Screw (K)	1 x Wall Bracket (L)	8 x Screw (P)	8 x Backply Stopper (Q)


Install 8 x Backply Stopper (Q) to Back Panel (10) using 8 x Screws (P).
Install 1 x Wall Bracket (L) to Top Panel (1) using 1 x Screws (K).
Tighten Back Panel (10) using 2 x Screws (K) as shown.




Step 12

You will need

12 x Shelf pin (M)

Insert 12 x Shelf Pin (M) into case assembly as shown.
Insert 2 x Side Shelf (7) and 1 x Middle Shelf (8) into case assembly as shown.



Step 13




We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Seek advice from a qualified trades person on how to attach this wall strap to your specific wall.

Screw and wall plug are not included.
Please use appropriate fixtures for your wall.
With assistance, move the product to the final position.
Attach the wall straps to the wall with the appropriate fixtures.
Make sure they are firmly attached and secure.


Step 14

You will need




4 x Full Curve Door Hinge (N)

Attach 4 x Full Curve Door Hinge (N) to 2 x Door (12) as shown.





Step 15



Attach 2 x Door (12) to case assembly as shown.





Step 16 The doors might out of alignment after the transportation.
If adjustment is necessary, please follow the steps below:



To move doors up or down:
loosen or tighten the screws on the hinge plate,
as shown.




To move doors in or out:
loosen or tighten the screws on the hinge plate,
as shown.



To move doors left or right:
loosen or tighten the screws on the hinge plate,
as shown.


Step 17

You will need




2 x Half Curve Door Hinge (O)

Attach Half Curve Door Hinge (O) to 1 x Door (12) as shown.





Step 18



Attach Door (12) to case assembly as shown.





Step 19 The doors might out of alignment after the transportation.
If adjustment is necessary, please follow the steps below:



To move doors up or down:
loosen or tighten the screws on the hinge plate,
as shown.




To move doors in or out:
loosen or tighten the screws on the hinge plate,
as shown.



To move doors left or right:
loosen or tighten the screws on the hinge plate,
as shown.


Step 20



After transportation, the push to open latches may need to be adjusted if it does not work well.


To adjust push-to-open latches, please follow the step below:
Push and release the piston once to allow the piston extend.
Gently turn the piston clockwise or anti-clockwise to adjust the position of the piston.
Push the piston once to retract the piston.

MAXIMUM WEIGHT CAPACITY OF THIS UNIT IS 30 KG.



Job Complete !

In the interest of our environment Please dispose of all packaging thoughtfully.



THIS PRODUCT IS FINISHED WITH FOIL LAMINATE

Avoid placing hot items directly onto the surface unless using a thick insulation material such as placemats or coasters. Heat may lead to discolouration or other damage to the surface of the product.

Use a soft cloth that has been dampened in water to clean the surface of this product. Do not use abrasive cleaners, furniture wax or polish on the surface of this product, as it may damage the surface.

CAUTION: FREQUENT EXPOSURE TO DIRECT SUNLIGHT OR SIMILAR SOURCES MAY CAUSE THE SURFACE TO DISCOLOUR OR FADE.