

ASSEMBLY INSTRUCTIONS

MODEL : CONCORD TABLE 1+4 (7006)

Read this instruction carefully, remove all wrapping material, staples and straps from the carton. See hardware and furniture part list. For guidance. Be sure you have all wooden furniture parts on a clean and soft surface to prevent from being scratched. Follow the figure to start assembling.

Caution:

1. Do not FULLY –TIGHTEN the nut or bolt until all nut or nut bolt is ready to assembled.
2. Do not OVER- TIGHTEN the nut or nut bolt to avoid causing damages to the thread.
3. Keep all hardware part out of reach of children.


PART LIST

No.	DESCRIPTION	QTY
A	TABLE TOP	1 PC
B	TABLE LEG	4 PCS


HARDWARE LIST

No.	DESCRIPTION	QTY
1	FLAT WASHER 6/19" 	8 PCS
2	SPRING WASHER 6/13" 	8 PCS
3	JCBC SCREW M6 X 70MM 	8 PCS
4	M4 ALLEN KEY 	1 PC

STEP 1



STEP 2



COMPLETED TABLE ASSEMBLY