# JAIR

## **User Manual**

### **Desk Chair**

- Breathable Mesh Backrest with Headrest
- Lumbar Support
- Breathable Fabric Cushion Seating Pan
- BIFMA X5.1 Certification





_	• Size	
-	• Color	
	<ul> <li>Materials</li> </ul>	
-	<ul> <li>Tilt Mechanism</li> </ul>	F
-	• Gas Lift Cylinder	
_	Caster Wheels	
_	Net Weight	
	Executive Standard	
-	• TVOC	
-		_

7

#### **PRODUCT DESCRIPTION**

26.77\*28.35\*44.29-47.05 inches

Multiple colors for selection

High-elastic Mesh, Knitted Fabric, PP+30% glass fiber High-density Foam, 9 Layers 13mm Heavy Duty Plywood

Regular Chassis, Thickened Steel Plate

TUV Certified 3-Level Powder Coated Gas Lift Cylinder

PA Universal Wheels

12.3KG

BIFMA 5.1

≤0.5mg /m²h

≤0.120mg /m<sup>2</sup>h

#### **USAGE & MAINTENANCE INSTRUCTION**



To prevent the chair star base from scratching, please **place the chair on flat ground;** 



Pay attention to the knives or other sharp items and prevent scratching to the fabric or armrests;



Acid and alkaline chemicals are prohibited to ensure the surface quality and life cycle of the chair;



Prevent **long-hours** direct **sunlight** in case of partial fading and yellowing;



Please **check** the **screws** and other accessories **termly** to ensure safety in use;



Wipe the fabric with clean **soft cloth**, and using a vacuum to clear the dust on the backrest, and between the seam of armrests and the seat;

#### **ASSEMBLY INSTRUCTIONS**



