

ASSEMBLY
INSTRUCTION

DRESSER+MIRROR

BEFORE ASSEMBLY







Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. Please take the time to read and follow the assembly instructions carefully.

Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Please separate, identify, and count all parts and metal hardware. Compare with part list to be sure all parts are present.


If hardware is missing or you have difficulty assembling this product, please call for us.

IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.

Part Lists				Hardware Lists			
NO.	Description	Sketch	Q'ty	NO.	Description	Sketch	Q'ty
1	Dresser		1 PC	A	Hex-Head bolts \varnothing 1/4"x32		6 PCS
2	Mirror		1 PC	B	Flat washer M6*19		6 PCS
3	Mirror supports		2 PCS	C	Allen key M4		1 PC

Step 1



Step 2

