

1. There are two cartons: one for the tabletop and the other for the leg.
2. Unpack the tabletop carton and put the tabletop upside down on the carpet
3. Unpack the leg carton and put the leg upside down on the tabletop.
4. Align the bolt holes on both items.
5. Put the bolts inside the holes with washers on and tighten all bolts.