
Model: MG 7409

Product Size: 940mm x 1930mm (Base Int Size)

Thank you for purchasing this product. Before starting assembly we suggest you spend a short time reading through this leaftlet, then follow the simple step by step guide.

Two people are needed to assemble this product.



TOP TIPS BEFORE YOU START!

IMPORTANT- READ CAREFULLY- RETAIN FOR FUTURE REFERENCE

- Please check that all parts & hardware are present before you start the assembly of your furniture.
- For ease and speed of assembly, we recommend that before you commence each step of the assembly, Please identify all the parts required for that step.
- We recommend that where possible, all items are assembled near to the area in which they will be placed in use, to Avoid moving the product unnecessarily once assembled.
- For the protection of your furniture, particularly items of high gloss finish, we recommend that the product is placed on a
 Protected surface during assembly to prevent any damage.
- 6. During assembly please take care not to over-tighten any fittings, as this may damage the product.

CARE AND MAINTENANCE OF YOUR FURNITURE

- Please periodically check all fittings and re-tighten as necessary.
- · To clean your item, please use a damp cloth and wipe clean.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- Please do not place hot items (e.g hot drinks) directly on the wood surface.
- Please do not drag or pull your furniture.

IMPORTANT INFORMATION

- Thickness of mattress should not exceed 150mm.
- 2. Children should be discouraged from playing on top of this bunk bed.
- The bunk bed should be checked periodically by the owner to ensure that the guardrail, ladder, and other components are maintained in the correct position and state of repair and that all connectors are tight.
- A bunk bed is not to be placed near a ceiling fan unless the distance between the closest points on the ceiling fan bunk Bed is at lest 2 metres.
- 5. Use guardrails on both sides of upper bunk.
- Prohibit horseplay on or under bed(s).
- Prohibit more than one person on upper bunk.
- Use Ladder for entering and leaving upper bunk.
- If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against The wall to prevent entrapment between the bed and the wall.

STRANGULATION HAZARD:


10. Never attach or hang items to any part of the bunk bed that are not designed for use with the bed for example, but not limited to hook, belt and jump ropes.

Page: 1 of 22

Guide To Assembly Model : MG 7409

Tools Required For Assembly







DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT. USE OF POWER TOOLS WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.




Approximately 2 hour




2 People Required


Rubber Hammer




Measure









Page: 2 of 22

Part List Model: MG 7409

	Carton 1 of 3			Carton 3 of 3	
No.	Part Name	Pcs	No.	Part Name	Pcs
20	Left End Panel (Bottom)	1	01	Plinth Panel (Cabinet)	2
22	Left End Panel (Front)	1	02	Bottom Panel (Cabinet)	1
23	Left End Panel (Back)	1	03	Support Panel (Cabinet)	1
29	Right End Panel (Front)	1	04	Left Panel (Cabinet)	1
30	Right End Panel (Back)	1	05	Top Panel (Cabinet)	1
31	1st Ladder Step	1	06	Back Panel (Cabinet)	1
32	Back Panel	1	07	Right Panel (Cabinet)	1
33	Bottom Support Panel	2	08	Back Panel (Drawer)	2
36	Ladder Side Panel	1	09	Left Panel (Drawer)	2
41	Solid Wood Slat Base (16 pcs)	1 set	10	Right Panel (Drawer)	2
Assembly Instructions + Fitting List			11	Bottom Panel (Drawer)	2
7100	combination of the control of the co	ig List	12	Front Panel (Drawer)	2
Carton 2 of 3			13	Door (Left)	1
21		1	14	Bottom Panel (Desk)	1
24	Left End Panel (Center)	1	15	Back Panel (Desk)	1
25	Back Panel (Shelf) Top Panel (Shelf)	1	16	Support Panel (Desk)	1
26		2	17	Left Panel (Desk)	1
27	Center Support Panel (Shelf)	70	18	Right Panel (Desk)	1
28	Bottom Panel (Shelf)	1	19	Top Panel (Desk)	1
34	Right End Panel (Center) 2nd Ladder Step	1	38	Door (Right)	1
35	3rd Ladder Step	1			
	Back Side Panel				
37		1			
39	Side Panel	2	-		
40	Support Rail				
42	Ladder Bottom Support Rail	5			
43	Back Support Rail	1	-		
44	Brace	2	J		

Page: 3 of 22

Part List Model: MG 7409 **3**9x2 **⊕**x2 3 **3**1x16 ҈ **(1)** 29 **€** x2 26 3 2 Ø **@** 43 0 36 23 3 30 3 **⊕** 3 **©** 29 1 03 19 0 02 **③**x2 **⊕**x5 **⊕**x2 ①x2 Ø **03**x2 1 **1**0x2 ⅎ Ø 1 12x2 10x2 33

Page: 4 of 22

Fitting List

Model: MG 7409

	Carton 1 of 3	}			
	Fitting List		933		
No.					
Α	Cam Stud (small)	& Tangan	37		
В	Cam	8	47		
С	Contractfix Dowel	55.	10		
D	M6 Round Nut	O.	8		
E	45mm Chipboard Screw	3/	9		
F	38mm Chipboard Screw	*	8		
G	14mm Chipboard Screw	Shrip	36		
Н	M8 x 25mm Wood Dowel		95		
J	M6 x 45mm Wood Dowel		20		
K	M6 x 13mm Baller	8	10		
L	14" Drawer Slide (SJ)	Carlo State	2 set		
М	Hinges Arm (Dix)	A 183	4 set		
N	5.5" PVC Bar Handle		4		
Р	20mm Handle Screw	Barre .	8		
Q	U Shape Caster	88	4		
R	M6 Cap Nut	9	4		
S	25mm Allen Bolt	9 5	4		
Т	M6 x 50mm Allen Bolt	9	8		
U	M6 x 45mm Allen Bolt	0	16		
٧	M6 x 35mm Allen Bolt	9	6		
W	M6 x 30mm Allen Bolt	0	36		
Х	M6 x 25mm Allen Bolt	9	5		
Υ	M6 x 12mm Allen Bolt	ॐ	4		
Z	M6 JCN Nut	9	6		
Z1	M6 Allen Wrench	1	2		

Caution

There are many small components used in the construction of this unit. These loose items should be kept away from young children whilst assembling your unit. As an extra precaution, screw cover caps should be permanently fixed in position. (Where applicable)

USEFUL HINTS & TIPS

Two people will be required to assemble this unit

Please keep this assembly instruction for future reference


Page: 5 of 22

Guide To Assembly Model: MG 7409 WHEN FITTING CAMS To Assembly the Drawer Slide, Please Follow Step as Below ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING BOLT Second Hole Last Hole TURN CLOCKWISE UNTIL SECURE (G G FRONT (00 00 BACK CORRECT WRONG 1 A x 10 L x 2 sets B x 10 G x 20 H x 24 01) x2 $M \times 4$ 03 隐 G

Page: 6 of 22

Guide To Assembly Model: MG 7409 2 3 ₫ 0 j x 4 02 @ 1 Ð **@** 5 4 with Edging B **@** D ❽ × D 6 N 0 x 5 X 1

Page: 7 of 22



Page: 8 of 22


Guide To Assembly Model: MG 7409 8 9 E x 1 D (E) 3 x 2 × Ð Ø 1 ₲ Ø 10 11 D 12 13 ❿ x 2 X x 5 Ð 1 12 Q x 4 with Lock Rx4 S x 4 S Q

Page: 9 of 22

Guide To Assembly Model: MG 7409 13 Ax7 J x 20 K x 10 B x 10 10 C x 10 28 K K 22 C K K C **(c)** C 23 K 20 K K C K C 29 K (C) K C 30 C

Page: 10 of 22

Guide To Assembly Model : MG 7409



Page: 11 of 22

Guide To Assembly Model: MG 7409 16 A x 7 B x 14 H x 43 25 Ø **33**x2 Turn Over 36 36 34 23 x2 35

Page: 12 of 22

Guide To Assembly Model: MG 7409 18 17 E x 2 with Edging E E 26 3 3 X x 5 1 19 20 Ex2 3 33 1 1 32 D E E 21 D 32 х3 X 29


Page: 13 of 22

Guide To Assembly Model: MG 7409 22 32mm 42mm 33 34 29 : 1 × 4 x 2 23 36 × (1) x 3

Page: 14 of 22

Guide To Assembly Model: MG 7409 24 23 x 2 7 **Hold This Panel** 25 x 2 X 22

Page: 15 of 22



Page: 16 of 22

Guide To Assembly Model: MG 7409 28 D x 4 Ex4 T T x 4 E 2 E E T E 0 2 D 29 Ux2 V x 3 Z x 3 0 (Z) Z V Z v U


Page: 17 of 22

Guide To Assembly Model: MG 7409 30 D x 4 V x 3 V 0 Z x 3 0 v Turn Over v **\$ Z** (8 (D) \$ **Z** \$ (**z**) 37 (D) (D) 31 T x 4 T U x 2 (U) 3 T U


Page: 18 of 22

Guide To Assembly Model: MG 7409 32 W x 4 40 0 33 W x 32 4


Page: 19 of 22



Page : 20 of 22





Page: 21 of 22




Page: 22 of 22


Adjusting Possibilities







Depth Adjustmentafter loosening the hinge arm mounting screw





Lateral Adjustment by adjusting screw





Vertical Adjustment via mounting plate (via slots or, if in two pieces, via screw)