




# Outdoor Sofa Set

<div>2.0 hrs</div> <div>APPROXIMATE ASSEMBLY TIME</div>	<div>2 PERSON ASSEMBLY</div> <div></div>	<div>FLOOR AREA 2M x 2M</div> <div></div> <div>REQUIRED ASSEMBLY SPACE</div>
---	--	---



# Outdoor Sofa Set

## Tips before you start:


1. Please check that all parts are present before you start the assembly of your furniture.
2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
3. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble your product safely.
4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
5. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
6. During assembly please take care not to over-tighten any fittings, as this may damage the product.
7. Always place the product on a flat, steady and stable surface.
8. Do not stand on the product. Do not use the product as a stepladder.
9. This product is intended for indoor, household use only as it is a non-industrial product.
10. Please use caution and care when lifting the product to avoid personal injury and/or product damage.

## Care and Maintenance of your Furniture

- ☒ Please periodically check all fittings and re-tighten as necessary.
- ☒ To clean your item, please use a damp cloth and wipe clean.
- ☒ Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- ☒ Please do not place hot items (eg. hot drinks) directly on to the surface.
- ☒ Please do not drag and pull your furniture.

# Outdoor Sofa Set

## HARDWARE LIST




25 x A  
Bolt



33 x B  
Washer




1 x C  
Allen Key




8 x D  
Bolt


## PARTS LIST




1 3 PCS




2 3 PCS




3 2 PCS




4 2 PCS




5 4 PCS




6 2 PCS




7 1 PC




8 1 PC



9 1 PC



10 2 PCS



11 1 PC

# Outdoor Sofa Set

## STEP 1

Fix part 4 to part 3 using bolts (A), washers (B) and allen key (C), as shown.




A x 4



B x 4



C x 1



**x2**

# Outdoor Sofa Set

## STEP 2

Fix part 1 to parts 3 and 4 using bolts (A), washers (B) and allen key (C), as shown.




A x 6



B x 6



C x 1



**x2**

# Outdoor Sofa Set

## STEP 3

Fix part 2 to parts 3 and 4 using bolts (A), washers (B) and allen key (C), as shown.




A x 6



B x 6



C x 1




**x2**

# Outdoor Sofa Set

## STEP 4

Place parts 5 and 6 into assembled unit, as shown.



**x2**

# Outdoor Sofa Set

## STEP 5

Fix part 8 to part 7 using bolts (A), washers (B) and allen key (C), as shown.




A x 3



B x 3



C x 1





# Outdoor Sofa Set

## STEP 6

Fix part 1 to parts 7 and 8 using bolts (A), washers (B) and allen key (C), as shown.




A x 3



B x 3



C x 1



# Outdoor Sofa Set

## STEP 7

Fix part 2 to parts 7 and 8 using bolts (A), washers (B) and allen key (C), as shown.



A x 3



B x 3




C x 1



# Outdoor Sofa Set

## STEP 8

Place parts 5 and 9 into assembled unit, as shown.




# Outdoor Sofa Set

## STEP 9


Fix parts 10 to part 11 using washers (B), allen key (C) and bolts (D), as shown.




B x 8



C x 1




D x 8



# Outdoor Sofa Set

## STEP 10



Your Outdoor Sofa Set is ready for use.

**Maximum recommended weight for 2 seater sofa is 200kg, single sofa is 100kg and table is 20kg.**