



TEMPLE & WEBSTER

Assembly Instruction

Rhet 180cm TV Unit




Panel No	Panel Sizes	Quantity	Panel No	Panel Sizes	Quantity
1	1800*400*16	1	10	871*160*16	1
2	1800*400*16	1	11	871*160*16	1
3	348*399*16	1	12	825*80*12	2
4	348*399*16	1	13	338*100*12	2
5	348*399*16	1	14	350*80*12	2
6	885*358*5	1	15	350*80*12	2
7	885*358*5	1	16	835*348*5	2
8	872*350*16	1	17	1740*50*16	2
9	875*60*16	1	18	308*50*16	3




Fittings



A=31




B=18




C=31




D=51




E=8



L=4



F=1



N=2



O=20





P=20





M5. 5*12

V1=16




Tools Needed




STEP 1




STEP 2







STEP 3 Separate the drawer runners




Push down the small lever and pull the two pieces apart




STEP 4




STEP 5




STEP 6





STEP 7




STEP 8




STEP 9




STEP 10




STEP 11



STEP 12








STEP 13



repeat for 2 drawers


STEP 14



The drawers will allign evenly when you ensure the screw is in the same place


repeat for 2drawers

STEP 15




*If drawers are stiff or uneven, adjust the position of the screws on the drawer runners.
Try to keep all screws in the same position.*



STEP 16




STEP 17




STEP18



STEP19



萨哈电视柜三胺邮购包装



Panel No		Panel Sizes	Quantity
19	护角	50*50*50	8
20	泡沫	1800*400*10	2
21	泡沫	440*115*40	2
22	泡沫	1800*115*20	2
23	泡沫	400*400*30	1
24	泡沫	1400*50*30	1
25	泡沫	473*350*15	1
26	泡沫	400*60*10	1
27	泡沫	915*50*110	1

Panel No		Panel Sizes	Quantity
28	泡沫	475*40*10	1
29	泡沫	200*137*10	1
30	泡沫	924*10*15	1
31	泡沫	260*58*15	1
32	泡沫	1800*80*15	1
33	泡沫	400*30*5	1
34	泡沫	1770*42*5	1
35	纸盒	内径1890*450*125	1