


ASSEMBLY INSTRUCTIONS

Dion Herringbone 200cm TV Unit



Two people required

www.templeandwebster.com.au

Keep these instructions for future reference

Assemble the furniture on a soft level surface to avoid damaging the furniture or your floor.

Parts of the assembly will be easier with 2 people.

We recommend furniture be assembled near where they will be placed, to avoid moving the product unnecessarily once assembled.

If there is a need to move the furniture, please remove all loose items and have extra hands to help lift the furniture to the desired location. Dragging the furniture will damage both the furniture and the floor.

Regularly check and re-tighten (if necessary) all bolts on furniture that you have assembled yourself.

Care and Maintenance of your Furniture

Wipe clean with a damp cloth. Use only water or a gentle detergent.
Wipe dry with a clean cloth.



WARNING:

It is **STRONGLY RECOMMENDED** that you **ANCHOR** this product.

Toppling furniture can cause serious injuries and death.

This product has been supplied with a bracket. To prevent your furniture from tipping forward it is strongly recommended that you securely attach this product to a wall or other solid surface, using the brackets provided and appropriate fixings.

IMPORTANT:

Regularly check that anchors are securely maintained.

Use safety drawer locks to prevent children climbing.

Stability of tall items may be affected by thick pile carpet or uneven floors.

Do not place unanchored televisions on furniture.


CAUTION:

For your safety when attaching the anchor fixings, please note the following:


- Check for any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure, please seek professional advice from a qualified tradesperson)
- Walls are constructed from different materials, for example, masonry (solid brick) or plasterboard lined cavity walls (hollow). It is important that you use the appropriate wall fixings for your wall type. If unsure, please seek professional advice on how to attach this safety bracket to your specific wall.
- Your local hardware store will have the necessary drills and fixings and can offer advice if needed. If in doubt, engage the services of a qualified tradesperson to install and anchor the product.

Tools Required


Time Required




DO NOT USE




Mallet



Flat head Screwdriver



Cross Screwdriver



60 min


Parts List

People Required


- | | | | |
|---------------|----------|-------------|-----------|
| Top Panel | (P1); | Support Leg | (P8); |
| Left Side | (P2); | Left Door | (P9); |
| Right Side | (P3); | Middle Door | (P10); |
| Divider Panel | (P4); | Middle Door | (P11); |
| Base | (P5); | Right Door | (P12); |
| Back Panel | (P6); | Shelf | (P13) x2. |
| Leg | (P7) x4; | | |



TWO PERSON RECOMMENDED



Hardware/Fittings



M8x60mm Bolt x 8

①




Ø8mm
Spring Washer x 8

②



Ø16mm Washer x 8

③




Ø6.5x44mm
Connecting Bolt x 8

④




Ø15x12mm
Locking nut x 8

⑤




Ø8x30mm
Wood Dowel x 12

⑥




Ø3.5x16mm
Screw x 28

⑦




Ø3.5x16mm
Screw x 28

⑧




Hinge x 4

⑨



Hinge x 4

⑩




Bracket x 2

⑪




Ø5x16mm
Shelf Support x 8

⑫




70mm
Handle x 4

⑬




4mm Allen Key x 1

⑭




5mm Allen Key x 1

⑮




M6x50mm Bolt x 8

⑯




Ø10x12mm Nut x 8

⑰



Ø20mm Felt pad x 4


⑱



Door stopper x 2



⑲

1






Insert 12 x Wood Dowels (6) into Left Side (P2), Right Side (P3) and Divider Panel (P4).
If necessary, gently tap the wood dowels with a mallet.

2





Attach 4 x Legs (P7) to Base (P5) using 8 x Bolts (1) , 8 x Spring Washers (2) and 8 x Washers (3) .
Tighten the bolts with Allen Key (15) .

3




Attach Left Side (P2), Right Side (P3) and Divider Panel (P4) to Base (P5) using 8 x Bolts (16) and 8 x Nuts (17) . Tighten the bolts with Allen Key (14) .

4






Loosely attach 2 x Brackets ⑪ to Top Panel (P1) using 4 x Screws ⑧.
 Fix 2 x Door stopper ⑲ to Top Panel (P1) using 4 x Screws ⑦.

5




Screw 8 x Bolts ④ into Top Panel (P1).

6




Attach Top Panel (P1) to Left Side (P2), Right Side (P3) and Divider Panel (P4) using 8 x Locking Nuts (5). Use a screwdriver to turn the nuts clockwise to lock. Attach 4 x Felt Pads (18) to the 4 x Legs (P7).

7





AA = BB




Place Back Panel (P6) onto the back as shown.

If necessary, adjust the assembly so that the diagonal measurements of the assembly are equal.

Fix the Back Panel (P6) to the Bottom, Left, Right Sides, Divider and Top Panel using 24 x Screws (8) as shown. With help, carefully turn the TV Unit over.




With help, carefully turn the TV Unit over.








- I. With help, move the TV Unit into position. Mark drilling points on the wall.
- II. If necessary, remove the TV Unit and drill holes with sizes suitable for your wall fixings.
- III. Install wall fixings in the holes.
- IV. Fix the wall brackets to the wall with appropriate wall fixing screws.
- V. Fasten the wall brackets to the underside of the top panel.

9



Insert 8 x Shelf Supports (12) into desired locations on the Side and Divider panels.
Gently place the 2 x Shelf (P13) as shown.


10



Fix 2 x Hinges (9) to Left Door (P9) using 4 x Screws (7) .






Fix 1 x Handle (13) to Left Door (P9) using 2 x Screws (7) .

11



Attach the door on the cabinet as shown.


12



Fix 2 x Hinges ⑩ to Middle Door (P10) using 4 x Screws ⑦.






Fix 1 x Handle ⑬ to Middle Door (P10) using 2 x Screws ⑦.

13



Attach the door on the cabinet as shown.


14



Fix 2 x Hinges ⑩ to Middle Door (P11) using 4 x Screws ⑦ .






Fix 1 x Handle ⑬ to Middle Door (P11) using 2 x Screws ⑦ .

15



Attach the door on the cabinet as shown.


16



Fix 2 x Hinges ⑨ to Right Door (P12) using 4 x Screws ⑦ .

Fix 1 x Handle ⑬ to Right Door (P12) using 2 x Screws ⑦ .

17





Attach the door on the cabinet as shown.

If adjustment is necessary, please follow the steps below:



To move doors up or down:

Turn the adjustment screw on both hinge plates on the door as shown.





To move doors in or out:

loosen or tighten the screws on the hinge plate, as shown.




To move doors left or right:

Loosen or tighten the screws to suit, as shown.



19



Assembly is complete.

**Please dispose of all
packing thoughtfully.**