


ASSEMBLY INSTRUCTION



MCCHCCDB/MCCHCCGR



ASSEMBLY INSTRUCTIONS




Step 1




PARTS AND HARDWARE

Note: Individual parts are not shown to scale.




Step 2




OPERATING YOUR UNIT


Step 3




Step 4




Step 5



Step 6



Step 7



Step 8

