


TEMPLE & WEBSTER

ASSEMBLY INSTRUCTIONS



Chelsea Click Clack 3s

Read first, enjoy forever

Assembly tips

- Assemble your product on a level surface and lay something soft underneath to protect potential floor damage.
- Don't over tighten screws. During assembly we recommend tightening to approximately 70% tightness. Only tighten hardware 100% when fully assembled.
- Keep children away from assembly area as bags and small parts can pose a choking hazard.
- Make sure you have enough space to layout parts before starting. We recommend assembling your item in its final location.
- Do not stand on or put weight on the parts as it may warp or damage product.
- We do not recommend the use of drills or power tools (unless specified) as it may damage the product or hardware. Use hand held screwdrivers only.
- It is best that two people assemble the product as some products may be too heavy for one person. Check this booklet for guidance.

Safety, care and maintenance

- To reduce the risk of injury, always secure storage furniture to walls and/or floors by using tip-over restraints.
- Never let children climb or hang on drawers, doors or shelves.
- To protect your product and your home, we recommend using coasters, placemats, rugs and other protective items.
- Screws may loosen over time. We recommend setting a reminder to tighten up every six months.
- Remove any liquid spills immediately using a clean cloth with mild detergent. Do not use bleach or abrasive cleaners. Always test any cleaning agent in an inconspicuous spot first to know if it is suitable.

Recycling

We hope that you love your product forever, but we know situations change. In the event that you wish to dispose of your product please consider some creative ways to give it a new home:

- If it's still in great shape, sell it on your favourite online marketplace!
- Give it a second life by affording it a fresh coat of paint.
- If you must dispose of it, why not donate it to your local charity or shelter for someone else to enjoy.


Please dispose of this product and packaging responsibly and recycle where possible. Scan the QR code to read more about Temple and Webster's commitment to a more sustainable future.



Parts list

ASSEMBLY INSTRUCTIONS

Chelsea Click Clack 3s MCCHCCDB/MCCHCCGR/MCCHCCNT




① 2pcs ② 2pcs ③ 1pc ④ 1pc

NUMBER OF PEOPLE REQUIRED FOR
ASSEMBLY:

2


TOOLS REQUIRED FOR
ASSEMBLY



⑤ 1pc ⑥ 1pc ⑦ 1pc

PARTS AND HARDWARE

Note: Individual parts are not shown to scale.



5*25*66
Ax1



Ø8*65mm
Bx2



Ø8*17mm
Cx2



M8
Dx2



Ø8*100mm
Ex8



M14
Fx1



M8*14mm
Gx8





Ø8*22mm
Hx8




Ø8*25mm
Qx10

1.

Find the parts from the storage bag.



2.




You will need:



Bolt 8pcs

3.




You will need:



Screw 6pcs

4.



You will need:



Nut 8pcs



Washer 8pcs




Wrench 1pc

**TEMPLE &
WEBSTER**

Damaged or missing parts? Or just need help?
Contact us on service@templeandwebster.com.au

5.



You will need:




Bolt 2pcs



Washer 2pcs



Washer 2pcs




Allen Key 1pc



Screw 4pcs


6.



**TEMPLE &
WEBSTER**

Damaged or missing parts? Or just need help?
Contact us on service@templeandwebster.com.au

7.



8.

