

# Hammock Chair Installation and Warnings

---

For eyebolt installation, ensure the eyebolt is screwed completely into a pre-drilled 3/16 hole. Pre-drilled hole must be directly in the centre of the stud for full weight bearing capacity. Failure to adhere to this can result in injury. Spinning or swinging can loosen and compromise the eyebolt strength. Hang the hammock chair by the O ring onto a pre-installed eyebolt/hook. Prior to each use of the hammock chair, inspect the ropes and other material including but not limited to: the mounting hardware, installation points, and objects supporting the hammock chair for signs of weakness or wear. Do not use if there are any signs that the material or supports are not in proper condition. Not recommended for use by children without adult supervision. The hammock chair is not designed for high, rough swinging or twisting movements.



## IMPORTANT

- Please read these instructions thoroughly before using your Hammock.
- Store in a cool, dry place when not in use.
- This is NOT a swing. Children using this product must be supervised at all times.
- Do not use if product has any faulty part, including the strings, fabric or hammock eye.
- Please check your hammock safe capacity each and every time prior to using. Do not use it more than the recommended safe capacity.
- Do NOT leave your hammock outdoors in the rain or expose it to direct sunlight. The fabric will deteriorate and the colours may run (not all our hammocks are colour-fast, contact us to confirm).

Imported and distributed by: New Aim Pty Ltd

Warehouse 5 / 3 Lennon Street West Melbourne VIC 3003 Australia

Made in China