


# SPECTOR®

## INTRODUCTION MANUAL

### Humidifier



**MODEL: AI1003-BK/AI1003-WH**

MADE IN CHINA  
100V-240V, 50/60Hz

**NOTE: Please read the manual carefully before using.**

## IMPORTANT SAFEGUARDS

**WARNING: TO AVOID THE RISK OF ELECTRICAL SHOCK, ALWAYS MAKE SURE THE PRODUCT IS UNPLUGGED FROM THE ELECTRICAL OUTLET BEFORE RELOCATING, OR CLEAN IT.**


1. In order to use this product effectively, first read the instructions carefully.
2. Do not disassemble, repair, or alter this product.
3. If the power cord is damaged, it must be replaced by the manufacturer for the product to be used safely.
4. Unplug the product while adding water to it or cleaning it.
5. Do not pull the power cord, unplug the power cable or touch the power cable with wet hands.
6. Do not bend or apply significant pressure to the power cord.
7. Warning: If water is left stagnant in the diffuser for a long period of time, microorganisms may grow in it. To prevent this from happening, please remove the water from the diffuser when it is not in use for long period of time.



8. Use the diffuser on a flat surface
9. Keep the diffuser away from heat sources and limit the product's exposure to direct sunlight.
10. Empty and clean the humidifier before storage.
11. Do not permit the area around the humidifier to become damp or wet. If dampness occurs, turn the output of the humidifier down. Do not allow absorbent materials, such as carpeting, curtains, drapes, or tablecloths, to become damp.
12. This appliance should not be operated by children.
13. The manufacturer is not responsible for any damages deriving from improper, wrong, or incautious use. To avoid any heating risk, unplug the appliance when not being used. Before cleaning, always unplug the appliance.

## OVERVIEW THE HUMIDIFIER

1. Top Cover
2. Control Panel
3. Main Body
4. Water Tank
5. Power Plug
6. LED Display
7. ON/OFF Button
8. Anion Button
9. Warm Misting Button
10. Misting Button
11. Auto Button
12. Timer Button
13. Remote Control



## TECHNICAL PARAMETERS

Product Name: Ultrasonic Humidifier	Model: AI1003-BK/AI1003-WH
Voltage: 100 - 240V~	Power: 110W
Frequency: 50/60Hz	Capacity: 6.0 Liters

## INSTRUCTIONS FOR USE

### 1. FILL THE WATER TANK

- Open the top cover (1) of the humidifier and fill with tap water and purified water.

#### ATTENTION!

- Make sure the product is unplugged from the mains before filling or refilling the water tank.
- Only use water in the water tank. Do not add any chemicals, oils or other additives.
- Only use cold or lukewarm water in the water tank. The water must not be warmer than 40°C.



### 2. PREPARING THE REMOTE CONTROL

Please follow the instructions below:




To operate the remote control for the first time, please pull the plastic protection out of the battery compartment.



Remove the plastic protection before use.

To change the battery please follow the instructions below:

1. Turn the battery cover and lift it up. Remove the old battery and then insert a new one.
2. Always make sure that the "+" polarity mark is facing up.
3. Tighten the battery cover.



Battery type: CR2025  
Quantity: 1pc

### 3. SET FUNCTIONS

#### ON / OFF

- Press the button of ON/OFF (7), to select power on / off the appliance.

#### ANION

- Press the button of Anion (8), to activate this function. The device generates negative ions that cause pollen, dust and pet hair to fall out from air, creating a more pleasant environment.

#### WARM

- Press the button of Warm (9), to activate this function, the humidifier working with warm misting.

#### MIST (1 / 2 / 3)

- Press the button of Mist (10), to activate this function.
- Press this button once, the product will operate at MIST 1.
- Press again to increase the mist power level to MIST 2.
- Press a third time to increase mist power level to MIST 3.

#### AUTO

- Press the button of Auto (11), to activate this function.
- When the ambient humidity is more than 70%RH, the misting stop working.
- When the ambient humidity is 50-70%RH, the misting working in MIST 1.
- When the ambient humidity is 30-50%RH, the misting working in MIST 2.
- When the ambient humidity is less than 30%RH, the misting working in MIST 3.

#### TIMER (1-12 HOURS)

- Press the button of Timer (12), to select it up to 12 hours.
- To set the timer for 1 hour, press the timer button once.
- Press the same button again for each one more hour you desire to set it. After pressing it 12 times (the display will show the number of scheduled hours) press again to cancel the timer.

#### REMOTE CONTROL

- All the function above can be setting by remote control.


#### LED DISPLAY

- All the above functional indicators can be displayed in the LED display, humidity and temperature display alternate automatically per 10s.

### CLEANING AND MAINTENANCE

#### PLEASE NOTE: THE WATER TANK MUST BE CLEANED AFTER USING IT 72 HOURS.

- If you do not use it for a long time, pick up the cover, keep the tank tilted in line with the base, please empty the water from the tank to avoid odor.



#### ATTENTION!

- When the humidifier works for 72 hours, the water shortage indicator is light on, the humidifier cannot work. There is a “buzzer” every 3S for 30S. Then press the power button for 3S to cancel the cleaning reminder, and the water shortage indicator is off. The humidifier works normally, and enter the next round of timing.

## Trouble shooting

Problem	Reason	Solution
The indicator light is not displayed	1.Power is not connected 2.The power switch is not on	1. Connect the Diffuser's power cord to a power outlet 2. Turn on the power switch
The indicator light is on, but no mist is coming out.	The mist is not turned on	Press the Mist button shown in Picture
Only a small amount of mist is coming out	1. The water is dirty, or the diffuser has been in storage too long. 2. The water temperature is too low. 3. The mist is set to the minimum setting.	1. Replace the water with clean water. 2. Use water at room temperature 3. Set the mist to the required level.
Mist spills from the tank cover or from around the nozzle	1. The lid is not closed properly	Place the lid properly
Abnormal noise	1. A lack of water is causing the diffuser to resonate. 2. The diffuser is not in a stable position.	1. Add water to the tank 2. Place it on a firm and stable surface.

## DISPOSAL

### Used electric household devices

1. If you do not want to use your electrical appliance any longer, return it free of charge to a recycling depot for used electric appliances.
2. Used electric devices do not belong in the household garbage (see symbol).

### Further disposal instructions

1. Return the electrical appliance in such a condition that its later re-use or recycling is not adversely affected. Batteries must be removed in advance and the destruction of parts which contain fluids must be avoided.
2. Electrical appliances can contain harmful substances. Improper handling or damage to the appliance can lead to health problems or water or ground contamination, when the appliance is recycled later.



## SPECIFICATION

PRODUCT: Humidifier

MODEL: AI1003-BK/AI1003-WH

POWER: 110W

VOLTAGE: 100V~240V, 50/60Hz



All images serve as illustrations only and do not always show exact representations of the device.

All rights reserved.