

Installation Steps for a Three-Tier Tool Cart

Step One

Installing 4 wheels (each secured with 8 small screws).



Step Two

Install 4 columns.



Step Three

Install the middle layer.



Step Four

Install the third layer and the push handle.



Problems encountered during installation and their solutions. What to do if the screw holes can't be aligned?

The product is fixed via the columns. Some holes are intentionally slightly tight to ensure the cart remains secure. As shown in the right figure, simply adjust with a screwdriver to complete the installation.

