


Before Assembly

IMPORTANT NOTE:

Make sure all parts and hardware are included and free of obvious Defect before disposing of any packaging. Place all wooden parts on a clean and smooth surface such as a rug or carpet toavoid the parts from being scratched DO NOT tighten all screws and bolts until completely assembled Assembly will require two people.

PART LIST 0 0 8 X3PCS X2PCS X4PCS 6 6 4 X2PCS X2PCS X4PCS HARDWARE IST B C A Η D F ⊢ 0.000 ODD M Ō 0 M4*12mm M6*14mm M6*35mm M6*30mm M4*35mm X4 PCS X1 PC X4 PCS **X12 PCS X12 PCS** X14 PCS **X14 PCS**



NOTED:

Do not fully tighten all bolts until all parts are in place. Failure to follow these instructions maycause the bolt to misalign during assembly.
To prevent injury and property damaged from unexpected tipping of furniture, we highly recommend installation of the anti-tip kit included with this product.

