


Assembly Instruction
Accent chair
IHD-AC18






Customer Service Before Return:






If part is missing or damaged, or you need help with assembly, please do not hesitate to contact us.


SELLER CONTACT INFORMATION:

contacts@ihomdec.com


| Component List | | | |
|----------------|--|-------------|-----|
| LABEL | | DESCRIPTION | QTY |
| A |  | Backrest | 1 |
| B |  | Seat | 1 |
| C |  | Front leg | 2 |
| | | | |

Component List


| LABEL | | DESCRIPTION | QTY |
|-------|---|-------------------|-----|
| H1 |  | Screw M8X45MM | 6 |
| H2 |  | Screw M8X70MM | 4 |
| H3 |  | Spring washer | 10 |
| H4 |  | Washer M8x22mm | 10 |
| H5 |  | Allen key | 1 |




1



2



3



4

