



ASSEMBLY INSTRUCTIONS

DRESSING TABLE



PARTS LIST




HARDWARE LIST

A		X18 SETS
B		X4 SETS
C		X16 PCS
D	LIGHT GROUP	X1 SETS
E		X4 PCS
F		X2 PCS
G		X24 PCS
H		X13 SETS
I		X 14 PCS


J		X2 PCS
K		X2 PCS

COMPONENT DESCRIPTION




NOTE:
PLEASE PAY ATTENTION TO THE DEPTH OF THE CONNECTING ROD. IT IS NECESSARY TO MAKE THE ECCENTRIC WHEEL JUST CLICK ON THE CONNECTING ROD. IF THERE IS DEVIATION, PLEASE ADJUST THE DEPTH OF THE CONNECTING ROD.

STEP 1




I X 8PCS

STEP 2




STEP 3




H X 8 SETS
E X 4 PCS
F X 2 PCS

STEP 4




B-a X 4 PCS
C X 8 PCS

STEP 5




A X 3 SETS

STEP 6




A X 3 SETS


STEP 7




STEP 8




STEP 9




STEP 10




STEP 11



STEP 12




STEP 13




A X 1SET
H X 3SETS

STEP 14




H X 2 SETS
J X 2 PCS

STEP 15




K X 2PCS


STEP 16




STEP 17



STEP 18




STEP 19



G X 8PCS

STEP 20



STEP 21

