


ASSEMBLY INSTRUCTION



TAB-756M




2 PERS



60 MIN

Important Tips and Maintenance




1.
Keep children and animals away from working area as smaller parts may cause choking if swallowed



2.
Never place liquids or anything damp upon furniture as it will mark, Ensure a coaster or running is beneath.



3.
Never use ammonia based cleaning products as it will damage the finish.



4.
To avoid fading, keep furniture out of direct sunlight.



5.
Use a soft or damp cloth (dry cloth) when wiping or cleaning surface.



6.
Two person are required



7.
Lay a soft matt down to protect the furniture pieces before and during assembly.

Assembling flat pack furniture could be slightly stressful. We recommend treating yourself to a cup of tea and taking a short rest after a few steps have been completed. Few tips to the assembling:

*Get ready

Space / Protect / Light / Safety

*Pre-battle prep

It is not tackling Mt Everest or running an ultra marathon but needs a certain amount of calm.

*Sort it out

Divide up the pieces of furniture before you start into relevant piles. Sorting and counting the screws.


*Read up

The instructions are just pictures with arrows and numbers, but familiarising yourself with the flow of the work stops you from making mistakes.

*On your marks

Remember, slow and steady wins the race

Feel free to contact your seller with any questions or comments




Before Assembly

Tips Before Your Start:


- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.

QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


CAM LOCK



When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.














Quickfit head should be in the centre of the cam lock when the two panels are joined.

Cam lock should be inserted before quickfit.


















Turn cam lock clockwise to tighten.

Parts List


①  x1	②  x1	③  x2	④  x1
⑤  x1	⑥  x1	⑦  x1	⑧  x1
⑨  x1	⑩  x2	⑪  x2	⑫  x2
⑬  x2	⑭  x1	⑮  x1	⑯  x1
⑰  x1			

Hardware List

A  x36	B  x36	C  Φ8x30mm x24	D  x1
E  Φ4x35mm x10	F  Φ3x12mm x24	G  x1	H  x18
I  M6x10mm x10	J  Φ7x40mm x2	K  x4	L  Φ4x30mm x4
M  Φ3.5x14mm x2	N  x2	O  x2	P  x4
Q  x4			
DL  x2	DR  x2	CL  x2	CR  x2


DO NOT USE any type of power tool when assembling the furniture.
It is easy to insert screws too far and cause damage.

Step 1




x2

Step 2





x2

Step 3




x2

Step 4




x2

Step 5




x2

Step 6




x2


Step 7




Step 8




Step 9




Step 10




Step 11




Step 12




Step 13




Step 14





Step 15





Step 16




Step 17




Step 18







Step 20




Step 21




Step 22




Step 23




Step 24




Step 25









Step 27



Step 28



⚠ WARNING



Children have died from furniture tipover.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.