


ASSEMBLY INSTRUCTIONS




This item shall be assembled by adult

In unsembled state, it might involve small parts and sharp points like screws which need to keep out of children's reach


- A 3.5*40 26pcs
 - B 3.0*30 4pcs
 - C 3.0*20 56pcs
 - D 3.0*12 24pcs
 - E 4pcs
 - F 2pcs
 - G 4pcs
-




Step1




Step2




Step3




Step4




Step5




Step6




Step7




Step8




Step9



Step10



Step11



Step12



Product care: Wipe with dry cloth occasionally.

Choking hazard: Contains unassembled small parts. Please keep small parts away from children.

Remove all packaging before giving the item to your child.

Adult assembly is required.

Recommended age 3 years above.

The product is warranted and distributed by New Aim Pty Ltd of Unit 3 Lennon Street West Melbourne VIC 3003 Australia