

BRONTE WALL-LIGHT

Installation Instructions



LIME
LIGHT[®]
LED lighting

Important for installation

Important: This light fixture must be installed by a qualified electrician in compliance with AS/NZ3000:2007 and Figure 1

Specifications

- **Input power:** Maximum voltage 240V, Frequency 50Hz
- **Globe socket:** 240V GU10, maximum 35 watts
- **Included luminaire:** Complimentary 5W LED globe(s) included. The included globe(s) are not dimmable.
- **Ingress Protection Rating:** IP65 (Dust tight, water jet proof). Suitable for outdoor installation. Not suitable for water immersion
- **Compliance:** The light fitting and luminaire(s) comply with all Australian requirements


Installation

- Do not install with other electrical devices on the same circuit as the LED luminaire such as ceiling or exhaust fans
- Make sure the electricity supply is disconnected before any installation
- Do not mix different luminaires on the same circuit – combine only with matching luminaries

Figure 1: Installation Steps


1. Remove and fasten plastic counter base to the wall

Note "UP" indication inside base




Applies to other base shapes too


2. Pull through power supply cable. Detach light connector




3. Connect Live, Neutral and Earth to connector as marked



4. Clip the connector back on its holder inside the base




5. Fasten the light fitting to the fixed counter base



6. Insert globe(s) (if not pre-installed) and firmly affix cap

Use only
Ø50mm
240V GU10
Max. 35W



Limelight
recommends
LED globes

- Subject to a 12 month standard limited Manufacturer Warranty. Included globes are not covered by warranty as they are complimentary
- Warranty terms available at www.RenovatorStore.com.au>Returns
- Modification of any component, or non-adherence to "Important for Installation" points above will void warranty