





ENTERTAINMENT UNIT

MODEL:EU-A17-RIZ-160-WD



ASSEMBLY INSTRUCTIONS

Please read instructions carefully before assembly.




Two persons and
tools required for
assembly

HARDWARE


A	x10	B	x10	C	x20	D	x10	E	x4	F	x8
											
7x35mm		15x12mm		Ø6x30mm		M4x40mm				M3x12mm	
G	x4	H	x8	I	x4	J	x1	K	x4	L	x18
											
M3x12mm										M4x14mm	
M	x4	N	x32	O	x2	P	x2	Q	x2	R	x22
											
		M3.5x14mm				M4x30mm					
S	x4										
											

PARTS

Wipe with dry cloths




1




P	x2	L	x2
		M4x14mm	

3




A	x10
7x35mm	

2







E	x4	F	x8
		M3x12mm	

4






C	x20
Ø6x30mm	

5




B	x10
 15x10mm	

7






K	x4	L	x16
		 M4x14mm	

6





D	x10
 M4x40mm	

8



J	x1	I	x4
			

9





rear panels


R x22




11



10






8x



H x8




12



S	x4	M	x4	N	x16
					3.5x14mm


13



G	x4
M3x12mm	



Pre-drilled hole at wall

14





Q	x2	O	x2
M4x30mm			

15








N	x8
M3.5x14mm	

16



N	x4
	
M3.5x14mm	

17



N	x4
	
M3.5x14mm	