
OUTDOOR RATTAN BISTRO SET

MODEL: OPS-BISTRO-3-BK/GY



ASSEMBLY INSTRUCTIONS

Please read these instructions carefully before assembling and using the product.

ATTENTION

- Please ensure that you have all the required parts before starting assembly.
- Do not use power tools to assemble this product.

SAFETY PRECAUTIONS


- Assembly of this set must be completed by a competent adult.
- Alwasy ensure that the furniture is on a flat and stable surface before use.
- Frequently check all parts to ensure that they are in good working order.
- Failure to comply with these instructions may cause physical injury or damage to the product.
- For safety purposes, do not exceed the maximum weight capacity.
- Do not stand or sit on the table.
- Do not stand on the seats.


CLEANING AND MAINTENANCE

- Wipe with a damp cloth and use a mild soap solution if needed.
- Do not use abrasive materials or cleaners or detergent chemicals.
- Store in a dry area that is not directly exposed to rhe elements, such as shed. Alternatively, use a garden furniture cover when the set is not in use.
- Avoid moving the set frequently as this may weaken the strcure.

PA	RT	QTY	PART	QTY
A		1pc	F © D6 washer	11pcs
В		1pc	G	1pc
С		1pc	H M6x35mm	4pcs
D		1pc		1рс
E M6x3	3 0mm	7pcs		1pc

CHAIR ASSEMBLY






STEP 1 Place A on a flat surface and attach it to C using 3 bolts (E) and 3 washers (F)

STEP 2

Attach B to C using 3 bolts (E) and 3 washers (F).



Attach D to arms of A and B using 2 bolts (H) and 2 washers (F). Next, secure bottom of D to back of seat using one bolt (E) and one washer (F).

B

E





TABLE ASSEMBLY



STEP 1

