
















# Assembly Instructions

OPS-TXL-CH



Do not fully tighten the screws until all of them are aligned properly with the holes.

If the legs are uneven on the ground during assembly, loosen some screws and add some pressure on the frame to ensure the legs are even. Then tighten the screws diagonally.

A	 left front leg	1PCS	
B	 right front leg	1PCS	
C		2PCS	
D		1PCS	
E	 6x70mm	4PCS	
F	 6x55mm	4PCS	
G		8PCS	
H		1PCS	
I		1PCS	
J		1PCS	
K		8PCS	

Don't let the product fully expose under the Sun or in rain.

The lifespan will shorten under prolonged sunshine and raining.