


Assembly Instructions

Sofa Chair

Do not fully tighten the screws until all of them are aligned properly with the holes.
If the legs are uneven on the ground during assembly, loosen some screws and add some pressure on the frame to ensure the legs are even. Then tighten the screws diagonally.

Caution:

Don't let the product fully expose under the Sun or in rain. The cushion cover will losing the water resistant under prolonged sunshine and raining.









OUTDOOR CHAIR SET ARMCHAIR

MODEL: OPS-SOFA-CH-BK

ASSEMBLY INSTRUCTIONS


Please read these instructions carefully
before assembling and using the product.

PARTS LIST


				 M6x30mm	
A 1pc	B 1pc	C 1pc	D 1pc	H 9pcs	L 1pc

ASSEMBLY STEPS



STEP 1







STEP 2




A 1Pc	B 1Pc	L 2Pcs	M 2Pcs	N 1Pc
M6*30	M6*35	M6*60		I 1Pc
H 8Pcs	J 4Pcs	O 4Pcs	P 4Pcs	Q 1Pc



		 M6*15		
G 1Pc	L 4Pcs	K 8Pcs	I 1Pc	

1



2

