

ASSEMBLY INSTRUCTIONS


Please read all instructions carefully before assembly.

BAMBOO WARDROBE

Model: WA-BM-RTN3D









Part A

4pcs






Step 4





Step 5


Part A












Step 8

Insert Part 5 (Long rear panel) and Part 6 (Short rear panel) along the grooves of Parts 1, 2 and 3.



Step 9

Part A 7pcs




Part D 2pcs





OPTIONAL •

Install Part D only if you wish to secure the product to a wall. See Step 13.

Attach Part 8 (Top panel) to the top with screws A.








Hinge Adjustments


If the doors do not appear square or aligned, loosen or tighten the appropriate screws in each case as illustrated.



Sideways adjustment

Adjust the clearance between the door and panel by turning screw 1.






Depth adjustment

Loosen screw 2, push the hinge arm forward or backward and then tighten screw 2.





Height adjustment

Loosen screw B, adjust the door height and then tighten screw B.



Step 12


Part D
Wall lock kit





OPTIONAL •

Do this step only if you wish to secure the product to a wall. It is highly recommended that you do so for safety reasons.



ATTENTION •

· Notice:

Recommended weight capacity:

Storage Shelf: **5kg** Garments Rod: **10kg**

Assembly must be done by adults. Check the product regularly for any damage. Keep away from any hazardous contents.

· Caution:

Do not place the bamboo product in extremely dry or humid environments. Bamboo is prone to cracking in moisture content under 6% or above 16%.

CARE AND MAINTENANCE OF BAMBOO FURNITURE

GENERAL

- · Periodically check all screws, bolts and joints connections and tighten them if necessary.
- Periodically check for any damage and deteriorated parts and components and seek repairs or replacements if needed.
- Do not allow any liquids to remain on the furniture as this may cause stains and allow the liquid to be absorbed into the finishes and materials.
- In some cases, this may also cause warping and/or cracking of the materials and finishes. Use coasters and placemats for all food and beverages.
- Do not place hot items, such as dishes, pots and cups, directly on the furniture. Use coasters and placemats for all food and beverages.
- · Keep sharp and pointed objects away from furniture to avoid damaging the surface and finish.
- · Do not place the furniture near hot objects, heating vents or heating equipment.
- · Do not place the furniture in moist areas such as bathrooms to prevent water damage.

CLEANING AND CARE

- Dust the furniture regularly using a soft cloth or microfibre duster to prevent dust build-up. Consider using a vacuum cleaner to thoroughly clean it.
- Only wipe and clean with a soft, damp cloth with a mild cleaning detergent. Use a toothbrush to clean hard-to-reach spots.
- Allow the washed furniture to dry in the shade rather than in the sun which can dry out bamboo too quickly.
- · Do not use a jet wash as this can damage the material.
- · Do not use chemicals with bamboo furniture as it may cause unnecessary staining.
- · If there are stains or liquid spills, clean it immediately to reduce the likelihood of the stain settling in and becoming permanent.

ENVIRONMENTAL

- Do not expose the furniture to direct sunlight. Use curtains and blinds to shield the furniture if direct sunlight is unavoidable.
- · In dry or hot indoor conditions, wipe the furniture with a cool, damp sponge often to prevent cracking.
- Bamboo furniture is prone to damage and fade with prolonged exposure to extremely high or low humidity conditions. Do not place them in such extreme conditions.
- Bamboo is porous and susceptible to moulding where placed around moist areas. As an optional
 protection for bamboo furniture, apply a bamboo sealant/varnish on it for durable protection
 against scratches, water, UV rays and other weather elements.

HANDLING

- Do not drag, push or pull furniture when moving them. Lift them up to avoid damage to the furniture legs and scratches on floors.
- · Do not sit on wet bamboo furniture as this will cause it to stretch or sag.
- · Avoid sitting or standing on armrests or use the furniture as a stepping stool for safety reasons.
- · Do not exceed the recommended weight capacities of the furniture specified.
- · Do not use the furniture for any purpose other than what is intended for.



Children have died from furniture tipover.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture