














<p>Ax4</p>  <p>6*50mm</p>	<p>Bx1</p>  <p>6*30mm</p>	<p>Cx4</p>  <p>6*20mm</p>	<p>Dx1</p> 
<p>Ex1</p> 	<p>Fx1</p>  <p>back</p>	<p>Gx1</p>  <p>seater</p>	<p>Hx1</p>  <p>M8</p>
<p>1</p> 		<p>2</p>  <p>Please tighten 4 screws A at 50% make sure all screw holes aglin.</p>	
<p>3</p> 		<p>4</p> 	
<p>5</p> 			



WARNINGS

- Do not stand on the product. Do not use it as a step ladder.
- Do not use the product until all screws are securely fastened.
- Do not use a knife to open any parts of the packaging.