



OUTDOOR SINGLE CHAIR

OPS-KUDA-2CH-GY









ASSEMBLY INSTRUCTIONS

Please read these instructions carefully before assembling and using the product.

CAUTION

- Do not fully expose the product to sunlight or rain for prolonged periods. The tempered glass might cracked and the cushion covers will lose their water-resistance properties.
- It is recommended to place the set under some shade or cover and not directly under the weather elements.

PARTS AND HARDWARE

A		1
B		1
C		1
D		1
E		1
F		1

Q	 M6x35	16
M		16
X		1

TROUBLESHOOTING GUIDE

PROBLEM	SOLUTION
The holes of some parts do not align with each other.	<ul style="list-style-type: none"> • Check that you have the right part for the connection and that the part is in the correct position and orientation. • Always dry fit the parts before connecting them with screws to ensure that you have the correct part for assembly. • Loosen the screws to re-align the connections before tightening them.
The product stands uneven and the legs are not touching the ground uniformly.	<ul style="list-style-type: none"> • Loosen some screws, apply some pressure on the product to ensure that all legs are in contact with the ground and then tighten the screws diagonally.
There are missing parts in the package.	<ul style="list-style-type: none"> • Please contact our Customer Service for assistance.

ASSEMBLY STEPS



ARMCHAIR ASSEMBLY

