



ASSEMBLY INSTRUCTIONS

Please read the instructions carefully before assembly and keep it for future reference.

TWO PERSONS AND TOOLS REQUIRED




Assembly and Maintenance Tips



1. Keep children and pets away from the working area as small parts may cause choking if swallowed.



2. Some furniture may require two persons to assemble for safety reasons.



3. To protect the surfaces of the furniture, lay the parts and perform the assembly on top of a soft mat (such as a carpet or cardboard).



4. Keep the furniture away from direct sunlight to avoid fading.



5. Use a soft, damp cloth to clean or wipe surfaces.




6. Never use ammonia-based or abrasive cleaning products to clean as they may damage the finish.



7. Do not place liquids or wet items on furniture as they may leave water marks/stains. Always use a coaster or runner to protect the furniture surface.


Assembly Checklist

Read




Read through the instructions carefully before you begin.

Prepare




Make sure you have all the required tools.
Never use power tools unless instructed.

Identify



Identify and lay out all of the components before you begin assembly.

Assemble






Please fully tighten all screws during the assembly process unless instructed not to do so.

Helpful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
 - ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
 - ! When assembling the product, it is recommended to do so on top of a soft surface such as a carpet or cardboard to avoid scratches and damages to the furniture surfaces.
 - ! Bulky items such as wardrobes should be assembled in the location when the assembled piece will be used to avoid moving them through doors or tight passages.
 - ! Never use any glue until you are certain that the parts belong together.
 - ! Periodically check that all connections are secured and follow all care and maintenance instructions stated.
 - ! If you encounter any assembly difficulties or missing components and/or hardware, please contact our Customer Service for further assistance.
-

Hardware List


Please ensure that all parts and hardware are in the packaging contents. If there are any missing parts and/or hardware, please contact our Customer Service as soon as possible.

Part A 28pcs Φ6x35mm 	Part B 16pcs Φ15x11.5mm 	Part C 2pcs Φ6x60mm 	Part D 16pcs Φ15x9.7mm 
Part E 16pcs M6x10mm 	Part F 6pcs ST7x50mm 	Part G 64pcs ST3.5x12mm 	Part H 16pcs ST4x30mm 
Part I 12pcs Φ8x30mm 	Part J 4 sets 300mm 	Part K 1pc Allen key 	Part L 4pcs Door hinge 
Part M 2pcs Shelf plug 			

Parts










Wipe only with
a dry cloth



Parts List

Please ensure that all parts and hardware are in the packaging contents. If there are any missing parts and/or hardware, please contact our Customer Service as soon as possible.

Part 1 1pc 	Part 2 1pc 	Part 3 1pc 	Part 4 1pc 
Part 5 1pc 	Part 6 2pcs 	Part 7 1pc 	Part 8 1pc 
Part 9 1pc 	Part 10 1pc 	Part 11 4pcs 	Part 12 4pcs 
Part 13 4pcs 	Part 14 4pcs 	Part 15 4pcs 	Part 16 2pcs 
Part 17 2pcs 			

STEP 1

Part A

4pcs
 $\Phi 6 \times 35 \text{mm}$



Part G

12pcs
 $\text{ST}3.5 \times 12 \text{mm}$









Part I

8pcs
 $\Phi 8 \times 30 \text{mm}$



Part J

2 sets
 300mm



Tighten Part A fully

STEP 2

Part C

2pcs

Ø6x60mm



Part G

10pcs

ST3.5x12mm



Part I

4pcs


Ø8x30mm



Part J


2 sets

300mm




Front

CL



CR

Front





STEP 3


Part B

8pcs

Ø15x11.5mm




STEP 4



STEP 5

Part F


6pcs
ST7x50mm



STEP 6


Part E

16pcs
M6x10mm



Note:


Part 16 and Part 17 cannot be
installed interchangeably.
Part 17 has a lock.




STEP 7

Part A

8pcs
Ø6x35mm







Tighten Part A fully



STEP 8

Part B

8pcs
Ø15x11.5mm



STEP 9

Part A

16pcs
 $\Phi 6 \times 35 \text{ mm}$



Part D

16pcs
 $\Phi 15 \times 11.5 \text{ mm}$



Part H

16pcs
 $\text{ST4} \times 30 \text{ mm}$








Part G

16pcs
 $\text{ST3.5} \times 12 \text{ mm}$



Part J


4 sets
 300mm




x4

Assemble 4 drawers

STEP 10



DRAWER INSTALLATION GUIDE



STEP 11


Part G

24pcs
ST3.5x12mm





Part L

4pcs



Part M


2pcs




Correct installation sequence:
First, install the door hinges on the door, then install the door on the cabinet.

Hinge Adjustments


If the doors do not appear square or aligned, loosen or tighten the appropriate screws in each case as illustrated.





Sideways adjustment
Adjust the clearance between the door and cabinet by turning screw 1.



Depth adjustment
Loosen screw 2, push the hinge arm forward or backward and then tighten screw 2.



Height adjustment
Loosen screw L, adjust the door height and then tighten screw L.



Locking all adjustments
After all adjustments have been done, tighten screw L to lock them.

CARE AND MAINTENANCE

GENERAL

- Periodically check all screws, bolts and joints connections and tighten them if necessary.
- Periodically check for any damage and deteriorated parts and components and seek repairs or replacements if needed.
- Do not allow any liquids to remain on the furniture as this may cause stains and allow the liquid to be absorbed into the finishes and materials. In some cases, this may also cause warping and/or cracking of the materials and finishes. Use coasters and placemats for all food and beverages.
- Do not place hot items, such as dishes, pots and cups, directly on the furniture. Use coasters and placemats for all food and beverages.
- Keep sharp and pointed objects away from furniture to avoid damaging the surface and finish.
- Do not place the furniture near hot objects, heating vents or heating equipment.
- Do not place the furniture in moist areas, such as bathrooms, to avoid water damage.

CLEANING AND CARE

- Dust the furniture regularly using a soft cloth or microfibre duster to prevent dust build-up
- Only wipe and clean with a soft, damp cloth with a mild cleaning detergent.
- Do not use abrasive cleaning materials such as scouring pads and chemical cleaning solvents to avoid damage to finishes and paintwork.
- After using or cleaning a glass table top, wipe it completely dry as leaving the glass unattended when wet may leave water marks that cannot be removed easily.
- For upholstery, vacuum regularly with a soft, non-metallic brush to remove dust and grime and to prevent overall soiling. Follow manufacturer's instructions for spot cleaning.
- If removable, wash upholstery covers periodically. If machine washable, use a cold wash cycle.
- Do not use a dryer. Only air dry the upholstery covers.

ENVIRONMENTAL

- Do not expose the furniture (including outdoor furniture) to direct sunlight. Protect your outdoor furniture with weather-resistant covers, and have curtains and blinds to shield indoor furniture if direct sunlight is unavoidable.
- Bamboo, rattan as well as wood-based furniture are prone to damage and fade with prolonged exposure to extremely high or low humidity conditions. Do not place them in such extreme conditions.
- For outdoor bamboo/rattan furniture, do not place the furniture in shady or moist areas to prevent it from moulding. Bring the furniture indoors during the off season or covered it with weather-resistant covers.

HANDLING

- Do not drag, push or pull furniture when moving them. Lift them up to avoid damage to the furniture legs and scratches on floors.
- Do not sit or stand on the armrests or use the furniture as a stepping stool for safety reasons.
- Do not exceed the recommended weight capacities of the furniture specified.
- Do not use the furniture for any other purpose other than what is intended for.

STORAGE

- Store furniture in a clean, dry environment when not in use.
- If possible, disassemble furniture before storing to save space and prevent damage during transportation.

SPECIFIC CARE

- Engage professional upholstery cleaning services for deeper cleaning if required.
- For genuine leather, suede leather or synthetic leather upholstery, use an appropriate leather conditioner to maintain its suppleness and appearance and prevent drying and cracking. The conditioner also adds a thin protective layer on the leather surface to facilitate easier cleaning.
- If a furniture polish is used for wooden furniture, make sure that it is of low alcohol content.
- To prevent rattan from becoming dry and brittle, spray water on the underside of the furniture piece every six months and wipe down with a dry cloth to remove excess water.
- As an optional protection for bamboo furniture, apply a bamboo sealant/varnish on it for durable protection against scratches, water, UV rays and other weather elements.