


Y511

Assembly
Instruction

| NO. | A | B | C | D | E | F | G | H | I | J | K | L |
|---------------|--------|--------|--------|---|----------|----|---|---|---|---|---|---|
| Fittings | | | | | | | | | | | | |
| Specification | ∅ 6X18 | ∅ 4X25 | ∅ 4X20 | | 58X58X18 | | | | | | | |
| PC | 34 | 7 | 4 | 6 | 2 | 34 | 4 | 4 | 1 | 1 | 1 | 3 |



Note: This product includes an anti-topple kit. Please use the kit for safety reasons.

Warning label:

| ⚠ WARNING | |
|---|---|
|  |  |
| <p>Children have died from furniture tipover.</p> <ul style="list-style-type: none">• ALWAYS secure this furniture with an anchor device.• NEVER allow children to stand, climb or hang on drawers, doors, or shelves.• NEVER open more than one drawer at a time.• Place heavy items down low. <p>NEVER put a TV on this furniture </p> | |