


SPECIFICATIONS



AVAILABLE IN



GS811
Chrome



GS811-40
Brushed Nickel



GS811-31
Brushed Carbon



GS811 MB
Matte Black



GS811-12
Brushed Gold

INFORMATION

MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
- Any damage caused in this way will not be covered by warranty.