







AVAILABLE IN











Chrome

GS897-40

GS897-31 Brushed Nickel Brushed Carbon Matte Black

GS897 MB

GS897-12 Brushed Gold

INFORMATION

MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
- Any damage caused in this way will not be covered by warranty.