PARTS LIST

- I. VESEL BODY
- 2. CARTRIDGE SEAL
- 3. O-RING 20X2.2
- 4. 25MM CARTRIDGE
- 5. DOME
- 6. LOCKNUT
- 7. RETAINER WASHER
- 8. DOME RETAINER
- 9. HANDLE (NOT INCUDED)
- 10. GRUB SCREW M4X5
- II. AERATOR
- 12. DRESS PLATE
- 13. SCREW
- 14. O-RING 39X2.5
- 15. HOSE EXTENSION ASSY HOT
- 16. HOSE EXTENSION ASSY COLD
- 17. FLEXIBLE HOSE 450MM HOT
- 18. FLEXIBLE HOSE 450MM COLD
- 19. FIXING PLATE
- 20. FIXING PLATE RUBBER
- 21. M8 NUT
- 22. M8 THREADED ROD
- 23. LOCKNUT SPANNER

MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
 Any damage caused in this way will not be covered by warranty.

