
PARTS LIST

- 1. ADAPTER
- 2. O-RING 11X2.0MM
- 3. GRUB SCREW M5X4
- 4. SPOUT
- 5. AERATOR RETAINER
- 6. O-RING 14X1.0MM
- 7. CONCEALED AERATOR
- 8. SPOUT PLATE



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
 Any damage caused in this way will not be covered by warranty.