


PARTS LIST

1. SWIVEL VALVE SEAT
2. MIXER LOCKNUT
3. MIXER COLLAR
4. NYLON RING
5. O-RING 41X3.0MM
6. VALVE SEAT GASKET
7. MIXER BODY
8. 35MM CARTRIDGE
9. MIXER HANDLE
10. PIN LEVER
11. SWIVEL DRESS PLAVE
12. GRUB SCREW M5X5MM
13. SCREW CAP
14. AERATOR GASKET
15. AERATOR RETAINER
16. AERATOR
17. FLEXIBLE HOSE 450MM HOT
18. FLEXIBLE HOSE 450MM COLD
19. THREADED ROD M8 X150MM
20. THREADED NUT M8
21. FIXING PLATE
22. RUBBER FIXING PLATE



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.