
PARTS LIST

- I. MIXER HANDLE
- 2. SPOUT 200MM
- 3. PIN LEVER
- 4. BACKPLATE
- 5. WALL BREECH
- 6. MIXER BODY
- 7. 35MM CARTRIDGE
- 8. GRUB SCREW M5X5MM
- 9. MIXER LOCKNUT M37X1.5MM
- 10. MIXER DOME
- II. AERATOR GASKET
- 12. AERATOR MAX FLOW
- 13. AERATOR RETAINER
- 14. O-RING 24.5X2.5MM
- 15. O-RING 43.5X2.5MM
- 16. O-RING 33X2.0MM



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
 Any damage caused in this way will not be covered by warranty.