PARTS LIST I. WALL BREACH 230MM 2. WALL MIXER BODY 17 3. 35MM CARTRIDGE 4. LOCKNUT (10) 5. MIXER HANDLE 6. GRUB SCREW M4X6 13 7. O-RING (12) 8. SCREW CAP 9. WALL BACKPLATE 10. SPOUT BLOCK 18 II. LOCATING PIN 12. WALL SPOUT 180MM 13. O-RING 14. RETAINING NOZZLE 3 15. AERATOR GASKET 7 19 16. GRUB SCREW M5X6 17. SPOUT ADAPTER 18. O-RING 19, GRUB SCREW M4X8 20. AERATOR 21. O-RING

2)

MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
 Any damage caused in this way will not be covered by warranty.