
PARTS LIST

- I. BASIN TAP ASSY
- 2. BASINT PIECE
- 3. LOCKNUT
- 4. SPOUT
- 5. NOZZLE RETAINER
- 6. AERATOR
- 7. GASKET
- 8. NYLON WASHER
- 9. MI 8 OUTLET TAIL
- 10. O-RING 16X2.0MM
- II. TAP BODY ASSY
- 12. SPLINE 89 MM
- 13. TAP FLANGE
- 14. NUT
- 15. ANTIVANDAL HANDLE KIT
- 16. HANDLE
- 17. WASHER
- 18. CONNECTOR
- 19. LOCKNUT



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
 Any damage caused in this way will not be covered by warranty.